



KING LONG
B U S E S

OPERATION MANUAL

User's Guide



King-Long XMQ6900 Series Tourist Bus

Xiamen King Long United Automotive Industry Co., Ltd.

FOREWORD

King-Long XMQ6900 series tourist bus keeps features of superior economy, security and comfort. It has stable performance, strong power, luxury interior trimming and high speed, which could meet applications of passenger inter-city transportation, touring and business affairs, etc.

As for the specifications introduced in relate to information of the driving and operation, service and maintenance of the XMQ6900 series tourist bus, please read them carefully and make proper operation, maintenance and repair so as to ensure it in good condition. Special hint: without authorization of Xiamen King Long United Automotive Industry Co., Ltd, never modify the electrical deployment of the whole vehicle, and should not lap the power supply line in disorder. Improper usage and repair may have a strong impact on service performance of the complete vehicle, and thus the manufacturer , Xiamen King Long United Automotive Industry Co., Ltd. will not takes the responsibility for the damages caused by them.

Any problem in service, please contact our special maintenance network or after-sales department. We will ensure timely and complete maintenance as well as original parts supply.

In order to satisfy all kinds of different demand of the consumers, we strive to improve the quality of the product continuously to optimize our products. We should not give any further notice for any modification of the product in advance . The contents on the instruction book can only be used as reference. If there are facts not comply with the manual, will be subject to the actual state of the products because for some device and items, the vehicle will be finally equipped only if they have been taken as optional configurations.

Final interpretive right of the instruction book belongs to the Engineering Academy of Xiamen King Long United Automotive Industry Co., Ltd.

Xiamen King Long United Automotive Industry Co., Ltd.

MAY. 2016

Contents

Vehicle's Picture

1. Foreword-----1-1

Contents

Contents-----1-2

2. Technical parameters and complete vehicle description

Technical parameters -----2-1

Introduction to data plate-----2-2

Product quality assurance -----2-3

Technical document -----2-3

Vehicle body structure-----2-4

Schematic illustration of the driver zone-----2-5

3 . Operation Instruction

Instrument instruction-----3-1

Illustration of switch and indicators-----3-2

Air conditioner control panel-----3-3

Transmission operation-----3-4

ABS operation-----3-5

ECAS operation-----3-6

Open or close the passenger door-----3-7

Door emergency switch-----3-8

Adjustment of the driver's seat-----3-9

Horn button-----3-10

Adjustment of the steering wheel-----3-11

Ignition switch-----3-12

Lamplight operating handles-----3-13

Wiper operating handle-----3-14

Passenger control panel-----3-16

Safety hatch-----3-17

Safety hammer-----	3-18
Relays & Fuses-----	3-19
Switch control box-----	3-20
4 . Vehicle starting and driving	
Check oil level of the engine-----	4-1
Check level of the coolant-----	4-2
Check fuel pre-filter with water separator-----	4-3
Check fuel level-----	4-4
Check vehicle lighting, intermittent lights and brake lights-----	4-5
Check the level of AdBlue and the daily maintenance of SCR system-----	4-6
Drain water in air tank-----	4-7
Check engine oil pressure-----	4-8
Check Pneumatic pressure-----	4-9
Check Tachometer working order-----	4-10
Steering wheel play-----	4-11
Check tire for abrasion and pressure and tire nut for fixture-----	4-12
Air cleaner-----	4-13
General leakages (water, oil, fluids and fuel) -----	4-14
Fastening and state of seat belts-----	4-15
Check emergency devices and driver’s tools (fire extinguisher) -----	4-16
Windshield wipers and conditions of wiper blades and arms-----	4-17
Electrical rearview mirror-----	4-18
Power steering system-----	4-19
General state and tension of drive belts-----	4-21
Check level of battery electrolyte-----	4-22
Procedures for engine start up-----	4-23
Engine shut down-----	4-24
Engine start up and shut down in the engine compartment-----	4-25
Starting the vehicle-----	4-26
Parking the vehicle-----	4-27

5 . Vehicle maintenance and service

General knowledge-----	5-1
Maintenance of engine and chassis subassembly-----	5-2
Body maintenance -----	5-3
ABS/EBS maintenance-----	5-4
Electrical system maintenance and notices -----	5-5
Tire transposition-----	5-6
Adjustment of the brake pedal freeplay-----	5-8
Bus cleaning-----	5-9
Cleaning air filter -----	5-10
Cleaning outside of radiator -----	5-11
Coolant specification -----	5-12
Fuel recommendation-----	5-13
Oil quality and specification recommendation-----	5-14
Breaking-in of a new vehicle-----	5-15
Daily Maintenance Operation-----	5-16
Maintenance per 5000km-----	5-17
Maintenance per 10000km-----	5-18
Maintenance per 20000km-----	5-19
Maintenance per 40000km -----	5-20
Maintenance per 80000km -----	5-21
Maintenance more than 80000km-----	5-22
Maintenance period chart-----	5-23
The introduction for the lubricate point location-----	5-24

6 . Common trouble and its eliminating method

Engine Common trouble and elimination-----	6-1
Propeller shaft-----	6-3
Transmission-----	6-4
Rear axle-----	6-5
Front axle and steering system-----	6-6


Braking system-----	6-7
Electrical equipment and the starting system -----	6-8
Air conditioner system-----	6-9
7 . Appendix	
Driver's tool table-----	7-1
Tightening moment of the bolts and the nuts in major position -----	7-2
Illustration for spare tyre dismounting & mounting-----	7-3
The operation tips for maintenance free battery-----	7-4
Table of lubricant, power steering oil, and grease-----	7-5
Air braking schematic diagram -----	7-6
Electrical elementary diagram of vehicle -----	7-7

Technical parameters of the complete vehicle
(Vehicle No: D2900633)

Product Model		XMQ6900	
Engine model		ISB6.7E5 250	
Engine type		In-line six-cylinder ,water-cooling four stroke direct-injection, electronically controlling, diesel engine	
Cylinder diameter × stroke (mm)		107×124	
Displacement (mL)		6700	
Compression ratio		17.3:1	
Rated capacity / rotation speed Kw/r/min		184/2500	
Max. torque / rotation speed N.m/r/min		950/1200	
Dimensions	Overall length (mm)		8995
	Overall width (mm)		2480
	Overall height (mm)		3435
	Wheelbase (mm)		4300
	Wheel track	Front (mm)	2090
		Rear (mm)	1860
	Minimum lift-off clearance (mm)		230
	Approach angle (°)		10
	departure angle (°)		8
	Front suspension / rear suspension (mm)		1905/2790
Rated passenger (driver included) (person)		≤39	
Mass parameter	Technically permissible maximum laden mass (kg)		14000
	Technically permissible maximum mass of combination (kg)		17500
	Technically permissible maximum laden mass for front axle (kg)		4500
	Technically permissible maximum laden mass for rear axle (kg)		9500
wheel	Tire size (front, rear)		275/70 R22.5
	Tire inflation pressure (kpa)		700
Performance parameter	Max. speed (km/h)		115
	Fuel consumption (L)		--
	Maximum gradeability (%)		30
	Min. turning diameter (m)		17

	parking braking ability (20% gradient)	parking for 5 minutes
Capacity data	Fuel tank (L)	200
	Engine oil (L)	26.5
	Transmission lubricant (L)	42(first oil fill); 24 (service oil change)
	Main retarder lubricant (L)	11
	Power steering hydraulic oil (L)	6~7
	Clutch oil (L)	0

Introduction to data plate



Bus data plate

The bus data plate may be affixed to either the upside of the front passenger door frame or to the side of the front passenger door step (the position may vary with vehicle model). There are many parameters on the plate, such as vehicle model, gross mass, vehicle serial number, vehicle capacity, VIN (short for vehicle identification number), chassis serial number, engine serial number, engine model, rated power, production data and etc..


Chassis data plate

The chassis data plate with vehicle identification number (VIN) is upon the front door.

Engine data plate

The engine data plate is on top surface or salient top position of the engine, whose position may be various according to different engine manufacturing plant.

The engine number is stamped on the left or right block of the engine, whose position may be various according to different engine manufacturing plant.



Product quality assurance

We insisted that the end user should make breaking-in maintenance of the rolling-out new vehicles in their initial driving mileage of 5000 km. Users must make proper operation and maintenance strictly according to relevant regulations in the instruction book. Please refer to “workshop manual” for product quality assurance and abide by related specification.

Technical documents

The instruction book is used combined to the following specification:

Engine operation instruction or service manual

Note: the instruction book should be modified according to specific configuration of vehicle

Body Structure

1. Structural style

Semi-integral body structure

2. Structure

The bodywork structure adopts closed girder construction of six major assembly parts, which are combined welded by rectangle steel pipes with advantages of strong structural stiffness, torsion resistance and bending resistance as well as relatively simple craftwork. Main components of skeleton have been performed anticorrosion treatment to ensure steady adhesion of coating and strong capacity of antirust and corrosion-proof.

3. Interior trim

The interior adopts flexible design and the floor adopts steel plate/wood block composite construction, and covered with anti-slip and antifriction leather with favorable sound insulation value.

4. Windows

The front windshield is the hyperboloid triplex glass fixed by the gluing; the rear windshields is fixed by harden glass, the side windows are sealing style, which are made of hollow glass. The driver's window is fixed with sliding window.

5. Baggage compartment

The baggage compartment adopts transverse run-through design, and they are all made of aluminum.

6. Seat

Driver's seat: Q15-2 driver seat, adjustable seat with high backrest and three-point belt.

Passenger seats: KE-1 type seat, with foot pedal and transverse movement function, high backrest, the all seats are equipped with three-points seat belt.

7. Interior accessory device

The vehicle is equipped with electronic clock, electric front windshield sunshade, driver side sunshade, electric driver window, safety hammer, emergency escaping window, curtain and luxury bilateral H type luggage rack, engine cabin fire extinguisher, electric mirrors, VDO travelling data recorder, reversal monitor, middle door (located in front of the rear axle), icebox, front and middle flip LCD TV, DVD player ,etc..

8. Air-conditioning system

Cooling system: WEBASTO top mounted dependent air-conditioning system..

Heating system: WEBASTO heating system. and NANFENG radiator system..

Defroster: NANFENG cooling /heating defrosting device

9. Door

The door adopts the full aluminum remote control out-swing pneumatic doors.

The out-swing door adopts the advanced electrically aerodynamic theory design, with the motion of opening and closing placidly、 agile、 safe、 lock credible and anti-clamp function.

A. Basic function

a. There are two electrically switches, the interior one is trigger touch-tone, which located on the dashboard of the front right side of the driver, the outside one is a remote control switch. , both switches can control the door.

b. When the circuit is in OFF position , the emergency switch can be used in the interior and exterior ,the emergency switch of the door is located inwardly upon the entrance of the door and outwardly behind the passenger door respectively, Please rotate the switch and throw open the door in emergency.

c. Commonly the door is closed, when touch off any electrically switch, the door would move placidly at a certain velocity, along with it, the step-lamp lights .when touch off the switch again , the door would return placidly at a certain velocity, after the door returned , the step-lamp goes out.

B. Hint:

- a. The door remote control acts only when the parking brake is on the parking gear.
- b. The door could only be opened when the external mechanical lock isn't locked up.
- c. In order to avoid impact, make sure that the door is completely closed or opened, before you make the next door switch operation.

Note: Deployment on the vehicle may be different with the above description because of different deploying requirement of the clients.

Schematic illustration of the driver zone



- | | |
|---------------------------------------|--------------------------------|
| 1 DVD/MP3 player | 10 Electric mirrors pushbutton |
| 2 Reversal monitor | 11 WEBASTO heating panel |
| 3 Rocker switch | 12 WEBASTO heater timing panel |
| 4 Light control handle | 13 Parking brake handle |
| 5 Combination instrument panel | 14 Travelling data recorder |
| 6 Steering wheel | 15 Radiator operation panel |
| 7 Wiper control handle | |
| 8 Gearbox operation panel | |
| 9 Fire extinguisher pushbutton switch | |

Instruction of instrument (VITI EDITION)




Figure-1 The Outline of ZB271M

The appearance of the ZB271M dashboard as shown in Figure-1 , it mainly contains eight indicator type measuring instruments, 29 icons which were lighted by the light-emitting diodes, one LCD screen and four buttons, dashboard pin definition go to **Appendix A**

2.1 Display Part.

- 1.Gear P—Brake gear, R—Reverse gear, N—Neutral gear, D—Drive gear, S—Safety belt.
- 2.Signal Bar. Go to **Appendix B**.
- 3.Speedometer .Display speed of car. Units :Km/h.
- 4.BarometerI and Barometer II. Display air pressure of car. Units: 0.1MPa .
- 5.Fuel gauge. Display amount of fuel. Units: Percentage.
- 6.Water temperature gauge .Display engine temperature of car. Units: °C.
- 7.Oil pressure gauge. Display oil pressure gauge of car. Units : 0.1MPa.
- 8.Voltmeter .Display Voltage of car. Unit: V.
- 9.Tachometer .Display rotate speed of car. Units: r/min.
- 10.LCD Screen. Display interface information, engine information and so on. Go to **Appendix C**.

2.2 Button part

ZB271M dashboard has four buttons,S1、 S2、 S3、 S4.

S1—Set Button. S2—Up Button. S3—Down Button. S4—Return Button.

S1 could set some information of dashboard, for example ,times, backlight, VehPPK and so on.

S2 and S3 could flip the screen up or down.

S4 Return main interface.

Remarks: Do not press S1 when flip the screen up or down.

3 Instructions

3.1 LCD Display

3.1.1 After power on as shown in Figure-2: Total Mileage, Trip Mileage A and Trip Mileage B

2012 08-07	12:20	
Total:	000 000	Km
TripA:	000.0	Km
TripB:	000.0	Km

Figure-2 Main interface

3.1.2The second interface display engine information, as shown in Figure -3。

Accumulated rotates and Engine running time.


2012 08-07	12:20
	RV: 000 000 K*10 Tt : 000 000 Hr TA: 00 : 00 HM

Figure-3 Engine information

3.1.3 The third and the fourth interface display information of Fuel and Mileage as shown in Figure -4 and

Figure -5.


2012 08-07	12:20	
	00 00	L(%)
	00 00	Km
	00 . 0	L/100

Figure-4 Fuel and Mileage information


2012 08-07	12:20	
	0000000000 .0	L
	0000000000 .0	L

Figure-5 Fuel and Mileage information

3.1.4 The fifth interface display CNG and Catalyst. as shown in Figure-6

2012 08-07	12:20	
C N G	0000	Bar
CATALYST	000	%

Figure-6 CNG and CATALYST

3.1.5 The sixth display inside temperature, outside temperature and engine compartment temperature. as shown in Figure-7




Figure-7 Car and Engine compartment temperature

3.1.6 The seventh、eighth、ninth、tenth and eleventh interface display ECM、TCM、ABS、AIR、Retarded information. as shown in Figure-8、9、10、11、12.




Figure-8 ECM Code




Figure-9 TCM Code

DTC OF ABS

NO: SPN FMI SA

Figure-10 ABS Code

DTC OF AIR

NO: SPN FMI SA

Figure-11 AIR Code

DTC OF RETARDER

NO: SPN FMI SA

Figure-12 Retarded Code

3.1.7 The thirteenth interface display online module. as shown in Figure-13.

MODULE

- | | | |
|---------------------------|---------------------------|--------------------------------------|
| <input type="radio"/> QKM | <input type="radio"/> ZKM | <input type="radio"/> DKM |
| <input type="radio"/> QDM | <input type="radio"/> HDM | <input checked="" type="radio"/> HKM |
| <input type="radio"/> QM | <input type="radio"/> HDK | <input type="radio"/> CGM |
| <input type="radio"/> TY1 | <input type="radio"/> TY2 | <input type="radio"/> TY3 |

Figure-13 Online Module

3.2 Dashboard Set

3.2.1 First, Press S1 go to set interface, Second, Press S2 and S3 flip the interface up or down.

Could Set Time、Set Backlight、Set VehPPK、Set MotPPR、Clear Trip A、Clear Trip B、ClearTA、Clear Oneway OC. as shown in Figure-14、15、16、17、18、19、20、21



Figure-14 Set Time




Figure-15 Set Backlight




Figure-16 Set VehPPK




Figure-17 Set MotPPR




Figure-18 Clear Trip A




Figure-19 Clear Trip B




Figure-20 ClearTA




Figure-21 Clear Oneway OC

3.2.2 Set Time .First press S1 go to set interface, Second press S2 or S3 choose Set Time position as shown in Figure-14, Third press S1 go to Figure-22.




Figure-22 Set Year

Finally press S2 and S3 could increase or decrease years. After set year, could press S1 choose Month、Day、 Hour、 Minute as shown in Figure-23、 24、 25、 26.And press S2 and S3 could set Month、 Day、 Hour、 Minute. After Set press S4 two times return main interface.




Figure-23 Set Month




Figure-24 Set Day



Figure-25 Set Hour




Figure-26 Set Minute

3.2.3 Set Backlight. First press S1 go to set interface, Second press S2 or S3 choose Set Backlight position as shown in Figure-15, Third press S1 go to Figure-27.




Figure-27 Set Backlight

Finally press S2 and S3 could increase or decrease backlight. After set backlight, press S4 two times return main interface.

3.2.4 Set VehPPK. First press S1 go to set interface, Second press S2 or S3 choose Set VehPPK position as shown in Figure-16, Third press S1 go to Figure-28.




Figure-28 Set VehPPK

Finally press S2 and S3 could increase or decrease VehPPK. After set VehPPK, press S4 two times return main interface.

3.2.5 Set MotPPR. First press S1 go to set interface, Second press S2 or S3 choose Set MotPPR position as shown in Figure-17, Third press S1 go to Figure-29.




Figure-29 Set MotPPR

Finally press S2 and S3 could increase or decrease MotPPR. After set MotPPR, press S4 two times return main interface.

3.2.6 Clear Trip A. First press S1 go to set interface, Second press S2 or S3 choose Clear Trip A position as shown in Figure-18. Third press S1 clear Trip A and auto return main interface.

3.2.7 Clear Trip B. First press S1 go to set interface, Second press S2 or S3 choose Clear Trip B position as shown in Figure-19. Third press S1 clear Trip B and auto return main interface.



















3.2.8 Clear TA. First press S1 go to set interface, Second press S2 or S3 choose Clear TA position as shown in Figure-20. Third press S1 clear TA and auto return main interface.

3.2.9 Clear One way OC. First press S1 go to set interface, Second press S2 or S3 choose Clear One way OC position as shown in Figure-21. Third press S1 clear One way OC and auto return main interface.

Appendix A ZB271M Dashboard Pin Definition

Table A Pin Definition			
Pin	Name	Color	Remark
1	VPP	Red	
2	GND	Black	
3	WAKE_UP1	Red	Connected to WAKE_UP2 inside
4	CANH1	Yellow	Connected to CANH2 inside
5	CANH2	Yellow	
6	CANL1	Green	Connected to CANL2 inside
7	CANL2	Green	
8	Empty		
9	Empty		
10	Empty		
11	WAKE_UP2	Red	
12	Empty		
13	Empty		
14	Empty		
15	Empty		
16	Empty		
17	Empty		
18	Empty		
19	Empty		
20	Empty		
21	Empty		

Appendix B ZB271M Signal Bar instructions

Icon	Name	Color
	Left turn light	Green
	Right turn light	Green
	Front fog light	Green
	ABS	Yellow
	Rear fog light	Yellow
	Preheater	Yellow
	Alarm of oil pressure	Red
	Engine fault	Yellow
	High beam	Blue
	Return	Red
	Alarm of gas pressure	Red
	Clearance Lamp	Green
	Avoid side slide	Red
	Charge	Red
	Parking light	Red
	Low beam	Green
	Alarm of water temperature	Red
	Alarm of Fuel Low	Red

Appendix C ZB271M LCD Alarm instructions







































Icon	Icon Name	Icon	Icon Name
	Front Door		Low Power
	Middle Door		Alarm of water level
	ECAS Fault		Concentrate lubrication
	Engine cabin temperature too high		Alarm of oil filter
	Lack water alarm of W.C		Alarm of oil filter
	Rear cabin door		Rear Door
	Left cabin door		Alarm of Retarded temperature
	Right cabin door		Fault of turn light
	Alarm of Oil Temperature		Alarm of ECAS
	Brake Light Fault	CRUISE	Cruise
	Safety Door		Brake Light
	Break Wear		Antifreeze controller








Illustration of switch and indicator











Number of switches , indicators and each own position may vary with the vehicle model and configuration state, please refer to the flowing sheet :

Switch	Name	Color	Function	Notes
	Daylight lamp	White	Pressed on top: interior lighting OFF Pressed on bottom: interior lighting ON	
	Hazard alarm lamp	White	Pressed on bottom: all turning indication lamps will turn on and flash	
	Luggage compartment lamp	White	Pressed on top: the luggage cabin lamp OFF Pressed on bottom: the luggage cabin lamp ON	
	Ventilator	White	Pressed on top: the ventilator is turned off Pressed on bottom: the ventilator is turned on	
	Front fog lamp	White	Pressed on top: the front fog lamp OFF Pressed on bottom: the front fog lamp ON	
	Rear fog lamp	White	Pressed on top: the rear fog lamp OFF Pressed on bottom: the rear fog lamp ON	
	Reading lamp	White	Pressed on top: the reading lamp OFF Pressed on bottom: the reading lamp ON	
	Front windshield defrosting switch	White	Pressed on top: turn off defrosting function Pressed on bottom: turn on defrosting function	
	Heating water valve switch	White	Pressed on top: the valve is switched off Pressed on bottom: the valve is switched on	

	<p style="text-align: center;">Fresh air ventilating switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: the ventilation function is switched off Pressed on bottom: the ventilation function is switched on</p>	
	<p style="text-align: center;">Horn</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: the electric horn is turned off Pressed on bottom: the electric horn is turned on</p>	
	<p style="text-align: center;">Disinfection function switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: the function is switched off Pressed on bottom: the function is switched on</p>	
	<p style="text-align: center;">Reversal monitor power switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: turned off the monitor power Pressed on bottom: turned on the monitor power</p>	
	<p style="text-align: center;">Body Kneeling function switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: turned on body restoration function, the body start restoring action. Pressed on bottom: turned on the body kneeling function, the body start kneeling action</p>	
	<p style="text-align: center;">Body raise/descend switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: turned on the body height adjust function, the body start raising Pressed on bottom: turned on the body height adjust function, the body start descending</p>	
	<p style="text-align: center;">Body 2th height adjusting switch</p>	<p style="text-align: center;">White</p>	<p>Pressed on top: the body height restore to the normal height state from 2th height location. Pressed on bottom: turned on the body height raise function, the body start raising the 2th height location.</p>	<p>When driving in rugged road, raise the vehicle body height for safe.</p>

Switch	Name	Color	Function	Notes
	Retarder foot-control function release switch	White	Pressed on top: the retarder foot-control function is turned on ; Pressed on bottom: the retarder foot-control function is turned off	
	Emergency power switch	White	Pressed on top: turn off the vehicle power Pressed on bottom: turn on the vehicle power	1) While only turn on the switch, could supply power only for 2 minutes; 2) Meanwhile, if also rotate the ignition key to ACC or ON shift, thus could supply power for long.
	Front windshield sunshade switch	White	Pressed on top: the sunshade will be raised Pressed on bottom: the sunshade will be descended down	
	Rearview mirror defrosting switch	White	Pressed on top: turn off defrosting function; Pressed on bottom: turn on the defrosting function.	
	Front passenger door switch	White	Pressed on top: close the door Pressed on bottom: open the door	
	Rear passenger door switch	White	Pressed on top: close the door Pressed on bottom: open the door	
	Flip TV switch	White	Pressed on top: turned off the power, folded the TV Pressed on bottom: turned on the power, unfolded the TV	

	<p>High/low shift switch</p>	<p>White</p>	<p>Pressed on top: turned on the high shift function Pressed on bottom: turned on the low shift function</p>	
	<p>Engine cabin fire extinguisher switch</p>	<p>Red</p>	<p>Pressed down : extinguisher will be activated</p>	<p>The powder will be burst out and coated on engine cylinder block so as to block up flame and combustion. Don't test to press this button down at normal condition</p>
	<p>Driver window raise/descend switch</p>	<p>White</p>	<p>Pressed on top: turned on the raise function Pressed on bottom: turned on the descend function</p>	
	<p>Driver window pre-heating & defrosting switch</p>	<p>White</p>	<p>Pressed on top: turned off the defrosting function Pressed on bottom: turned on the defrosting function</p>	
	<p>Engine Diagnose function switch</p>	<p>White</p>	<p>Pressed on top: turned off the engine diagnose function Pressed on bottom: turned on the engine diagnose function</p>	
	<p>Engine cruise function switch</p>	<p>White</p>	<p>Pressed on top: turned off the engine cruise function Pressed on bottom: turned on the engine cruise function</p>	<p>we advise clients not to use this switch</p>
	<p>Cruise set switch</p>	<p>White</p>	<p>Pressed on top: turned off the engine cruise set Pressed on bottom: turned on the engine cruise set</p>	<p>we advise clients not to use this switch</p>


Indicator lamp	Color	Function
 	Red	Engine fault alarm
	Yellow	Exceeding emission standard indication
 	Red	Gearbox oil temperature over-heat alarm
	Red	Gearbox fault alarm
 	Yellow	Kneeling function work indication
	Green	Body keep 2th height state indication
 	Yellow	ECAS alarm indication
	Red	ECAS function fault alarm
 	Yellow	Vehicle require maintenance indication
	White	Engine wait starting indication

CC350-355 series A/C Operation

Equipment Description

SPHEROS's air conditioner equipment, models CC350H roof top, are composed by two Evaporator modules, a Condenser module and a Compressor. The system is inter linked by copper pipe which conduct the refrigerating gas compressed at the compressor by means of its components. As a result, refrigeration takes place. The electrical system is composed by a power panel with fuses and relays as well as an electronic controller that controls the selected temperature inside the vehicle. The electrical system is inter connected to the vehicle alternator and battery.


Components Location



1、Introduce

CC350H is an air environmental control systems for vehicles with function to automatic control refrigeration and heating.

1.1 Control Panel Function Introduce:






- | | |
|---|--|
| 1. Internal / external temperature switch | 2. External temperature display lights |
| 3. Internal temperature display lights | 4. Upwards |
| 5. Downwards | 6. Air updates (fresh air optional) |
| 7. Automatic mode | 8. Air updates lights (fresh air optional) |
| 9. Automatic mode display lights | 10. Ventilation button |
| 11. Ventilation speed display lights | 12. Heating mode button |

1.2 Numeric Display







The two digits numeric display is used for informing the operator how the system is working. When there is no function active the display shows OF. Normally display shows the set point when in Auto Mode and the blower's speed when in Ventilation Mode.


1.3 Setpoint





Set point is the desired temperature inside the vehicle. To change it is necessary that the auto mode is selected. Press

. Then, the set-point temperature will be shown and may be adjusted by pressing  or .

1.4 Ventilation Mode

The ventilation function is activated by the key . There are three operation blower's speeds. To change the blower's speed the ventilation function must be selected. Press . Then, the speed will be shown and may be adjusted by pressing  or . When you select the ventilation function, the damper (air renovation) is automatically opened. For closing the damper, the operator must press the key  and . At this time the indoor air will be normal cycle.



Ventilation	Display Indication	LEDS
Off	u0	
Low	u1	
Medium	u2	
High	u3	

1.5 Fresh Air/Air Circulation



There are two system operation modes: Intelligent mode and manual mode.

The smart air mode automatically controls according to the temperature conditions (internal, external and for renovating the air inside the vehicle). The manual mode allows the driver to control the opening of external air manually.

When the auto mode is activated, it is selected smart air. This operation enables the damper to operate in a way that it always seeks for the best comfort and thermal balance conditions as well saving fuel.

To change the damper state, please press  and the panel shows the damper statue :

Indication	Damper state
OP	Open
CL	Closed

When the damper state is shown press  to open or  to close the damper door. The display point will turn off and the manual mode is taken over. After 10 minutes, the system returns to smart mode. In the smart air mode, the damper automatically opens, and after 10 seconds closed. Then 10 minutes later restart again, and circulate like this. This will just happens when the internal temperature is between 3° C over Set Point and 3° C below setpoint. The fresh air flap open and






close automatically and the cycle is according the parameters **dn** and **df**. According to industry standard of China, the **dn** parameter is 50s, and the **df** is 9min. They both can be reinstall in accordance with user's requirements.

When the external temperature is below 15° C in cool mode, the system tries to cool down only with fresh air. The clutch waits 1 minute to engage. After elapsed this time the system checks if temperature reduces at least one degree. These is repeated until the temperature didn't reduces 1° C each minute, then clutch is engaged.

1.6 Auto Mode

Auto mode provides a full automatic control inside the bus. You just need to press and set the desired temperature. The system is designed to work by itself in order to select the best operation mode to reach the set point.

In the auto mode, the blower's speed, is usually automatic. However the operator may fixed the speed manually, following these steps:

- Turn on the Auto Mode pressing  key;
- Press  key. The blowers speed will be shown on display during a few seconds;
- If the operator press  or  key while the speed is being shown, the speed led will turn on. This indicates manual speed mode;
- Use and keys to select the desire speed; To return back to automatic control, press  key.

1.7 Test Mode

The system offers a test mode to diagnose the whole device, with actuation of the outputs and checking of inputs.

Access to the module, in accordance with the following steps:

- Press simultaneously **AUTO** and **☸**, the numerical display will exhibit **--**, then enter the password **14**.
- Using the **▲** key to increment the decimal and **▼** to increment the unit.
- Press the **☸** key to confirm. If the password is wrong, the panel will display internal temperature. After the access password is confirmed, the control board will display "i", then the all input will be confirmed.
- Press **▼** to convert between input and output.
- Press **☸**, the control board will display **.i0** or **o0** to show it is input or output. If it is input (i), the LED indicator light 2 will reads the input state. If the light flashing, it shows the parameters input closed, and if not flashing, it shows parameters input open.
- If you choose output parameter (0), press **☸** to open and/or shut down. In this case, the LED light is on, and that indicate output parameters is on.
- Press **▲** or **▼** to convert between input and output. If open the output function, the all before set will be shut down.
- To withdraw the chosen input or output mode, please press **⏮**, and then press again, that will be ok.

Input	Funtion	LED On	LED Blinking
.i0	Pressure switches input	Both pressure switches are OK	One or both pressure switches in FAIL status. Check connections and pressure switches.
.i1	ICE Sensor-Freezing of evaporator serpentine input.	ICE sensor OK	ICE Sensor indicates that the system is frozen. Check ICE Sensor and connections.
.i2	Start heating system- Show the enter. The current heating state.	Heating plate GL-W002 is exist. Start it, that's OK.	Heating plate GL-W002 is not exist.

Output	Description
o0	Turns on blowers at low speed
o1	Turns on blowers at medium speed
o2	Turns on blowers at high speed
o3	Open air renovation damper
o4	Turns on fans(Condenser motors)
o5	Turn on water pump

o6	Opens roof heating valve(30%)(in case there is heating)
o7	Open roof heating valve (65%) (in case there is heating)
o8	Open roof heating valve (99%) (in case there is heating)
[H	Gas charge function, allows refrigeration to take place, independently the control

Function [H can make the air-conditioning to work not considering the internal temperature. When the internal temperature is not so high to start air-conditioning, but we want to start it to take test, we can use this function. All the other protection functions will be open in this mode.

The air-conditioning control system has other functions, such as record number of faults, the compressor's whole running time that from it starts and so on.

Pre-heater Operation (Webasto)

1. General

The standard digital timer enables you to preset the start of the heater operation up to 7 days in advance.

It is possible to program 3 different starting times, only one of which can be activated.

The standard digital timer features a wakeup alarm function.

When the ignition switched on, the timer displays the current time and the day of the week.

When the heater is switched on, the display and the buttons are illuminated.

After the power supply has been connected, all symbols on the display will flash.

The current time and weekday must be set.

2. Operation

The timer can be operated in that all flashing symbols can be adjusted by means of the 10 and 9 buttons.

If the buttons are not pressed within 5 seconds, the time displayed will be stored.

If the 10 and 9 buttons are pressed for more than 2 seconds, the fast time-setting mode is activated.

If the ignition is switched off while the heater is operating in the continuous mode, the remaining operating time of 15 minutes is displayed and the heater continues to operate for this period of time.

3. Switch the heater on

Manually: by pressing the button 8 (continuous heating mode)

Automatically: by programming the heater starting time

4. Switch the heater off

Manually: by pressing the button 8

Automatically: after the programmed operating time has elapsed.

With the heater running: by programming the remaining operating time

5. Setting time/day of the week


Press the 6 button for more than 2 seconds-time of the day if flashing-and set the clock using the 9 and 10 buttons. Day of the week is flashing – adjust the day of the week.

6. Viewing the time

With the ignition switched off: press the 6 button.

7. Programming heater starting time:

Standard Timer



1. heater “on” indicator
2. day of the week
3. time display
4. memory location
5. alarm indicator
6. time
7. program selection
8. instant heating
9. reverse
10. forward
11. panel

Press the 7 button – the memory location is flashing – using the 9 and 10 buttons set start of the heater operating time. Day of the week is flashing- set the day of the week. By repeatedly pressing the 6 button, memory locations 2 and 3 can be programmed or the time display mode can be reached.

8. Recalling/erasing preset times

Repeatedly press the 6 button until the desired memory location is displayed. To erase the preset time, press the 7 button several times until the time of the day is displayed instead of the memory.


9. Programming duration of operating time The heater must be switched off. Press the 9 button for 3 seconds – operating time is flashing – and set the desired operating time (10 to 120 minutes) using the 9 and 10 buttons.

10. Setting the remaining operating time



Set the desired remaining operating time (1 to 120 minutes) using the 9 and 10 buttons. The remaining operating time refers to the time the heater still continues to remain in operation and the ignition switched off.

11. Setting the wakeup time

A wakeup time can only be programmed on the standard digital timer. The wakeup time is not bound to a specific day of the week.

Repeatedly press the 7 button until the bell symbol  appears on the display. Set the desired wakeup time using the 9 and 10 buttons. The alarm clock turns off after 5 minutes or when one of the buttons is pressed.

12. Recalling/erasing the wakeup time

Repeatedly press the 7 button until the bell symbol  appears on the display – read off wakeup time. To erase the wakeup time: press the 7 button until the bell symbol  is no longer visible on the display.

13. remote control

Possible by means of an optional external “instant heating” button

14. Vehicles with ADR equipment

On ADR vehicles it is not possible to program a preset starting time. The remaining time is shown on the display while the heater is in operation. The clock can be set. The alarm clock function can be programmed on the standard digital timer.

NANFENG Panel Operation Description:


1

2

3

4

5

1. Heating panel power switch: while pressing the button 1, the panel lamps are turning on or turning off, meanwhile, the heating opened or closed.
2. MANUAL/AUTO mode setting : while pressing on the button 2, may change over different mode state, once in AUTO mode, the water valve would open automatically and keep heating for room as far as the room temperature is below the temperature value which the system was already pre-established in advance; once in MANUAL mode, the WATER VALVE lamp lit on, the water valve keep opening all the time..
3. Temperature setting : In MANUAL mode state, if intend to adjust the room temperature, may press button 4 or button 5 until your desirable temperature value, but your operation should be pressed on the button 3 simultaneously.

Gearbox Operation

Transmission model (Automatic gearbox ZF 6AP1200B)



Push-button control with diagnostics connector,
Variant with 3 push buttons, horizontally arranged (details may be different from illustration)

Fig.1



Push-button control with diagnostics connector,
variant with 6 push buttons, horizontally arranged
(details may be different from illustration).

Fig.2

Operation Instruction (as per Fig.1 or Fig.2 panels)

1.1 Push-button control with diagnostics connector

1.1.1 Variants

Variants: 3, 4, 5 or 6 push buttons for speed-range selection, horizontally or vertically arranged:

R = Reverse

N = Neutral

D = automatic forward driving range (Drive)

optional:

1, 2, 3 = limited forward driving ranges

For a description of the driving ranges see Section 1.2

1.1.2 Push-button illumination

Brightness levels 1 (low) and 2 (high) are available for push-button illumination.

Turning the vehicle key into driving position causes the system to perform an automatic illumination test. All push buttons will be illuminated for approx. 1.2 s at level 2 before the system changes to level 1 for easier location of the push buttons.

After depression of a push button it will be illuminated at level 2 as soon as it is accepted by the electronic control system.

Display of errors:

- **Illumination level 1 is retained despite depressed push button**

Possible causes:

- Information needed for illumination is not provided by the electronic control unit. In such a case, normal driving is still possible.
- Hardware defect on push-button selector

- **Depressed push button flashes**

Cause: Push button is not accepted by the electronic control unit (for potential cases see Section 1.3 and 1.4)

1.1.3 Push-button selector position

NOTE

If several push buttons are selected at the same time, the smallest gear locking button selected will be activated.

Example: If push buttons 3 and D are accidentally depressed at the same time, push button 3 will be activated.

1.2 Driving range

Driving ranges are selected through depression of the respective push buttons of the push-button range selector

(see Section 1.1), consult the vehicle operation instructions

for precise information about the gears engaged in each of the speed ranges.

A defined range of gears is assigned to each driving range. Gearshifts are only executed at shift points defined by the electronic control unit.

Manual intervention in the automatic shifting process (shifting through driving ranges) is not expedient.

**DANGER !**

If the push button "N" is depressed during driving operation, the power flow between engine and output will be interrupted.

Engine and retarder braking action are then lost.

Risk of accident! - Apply the brake!

For safety reasons, when faults occur in the electronic control unit, or whenever there is a power failure, the transmission will automatically select "Neutral".

1.3 Starting the engine

The engine may only be started under the following conditions:

- Vehicle standstill
- Activated service or parking brake
- Push-button selector in Neutral position ("N")

NOTE

Starting interlock: If the push-button selector is not in neutral position, engine start will as a rule be prevented. For details consult the vehicle operating instructions of the vehicle manufacturer.

It may be possible to start the engine when the push-button selector is not in neutral position. In such a case, the push button depressed will flash after the engine

Starts (see Section 1.1.2) and the transmission will remain in Neutral. To drive off, the push button "N" will then

Have to be depressed and subsequently (see Section.1.4) the desired driving-range push button on the push-button range selector.

CAUTION

Only jump-start on the battery, never on the starter! Do not turn the vehicle key while driving!

1.4 Engaging a gear

CAUTION

Never operate the push-button range selector and step on the accelerator at the same time!

Warm up the engine for about 5 minutes, with the push-button range selector in neutral position, after prolonged standstill at ambient temperatures below -20°C.

1.4.1 Standard

- Accelerator pedal in idling position
- $n_{Min} < 900$ rpm
- Vehicle standstill
- Activated service or parking brake
- Select desired driving range by depressing-
corresponding push button on push-button range
selector.

In the following cases engagement of a starting gear is prevented by the electronic control unit in spite of a selected driving range (push button depressed). In such

cases, the pushbutton depressed will flash (see Section 1.1.2)

- Accelerator pedal operated
- $n_{Min} > 900$ rpm
- Driving speed $>$ approx. 3 km/h and driving range
selected do not correspond to actual driving direction.
- Transmission oil sump temperature below -20°C .

1.4.2 Transmission with additional functions

1.4.2.1 Additional function “ Gear Release ”

(Additional installation by vehicle manufacturer,
recommended by ZF!)

Procedure as described under 1.4.1. In addition to the cases mentioned under 1.4.1, engagement of a starting gear is prevented by the electronic control unit in spite of a selected driving range (push button depressed) in the following case. In this case, the push button depressed

will flash (see Section 1.1.2)

1.4.2.2 Additional function “ Additional pushbutton reverse gear ”

For engagement of the reverse gear, depress the R push button of the push-button range selector and promptly also the R push button on the instrument panel.

Remaining procedure as described under 1.4.1

In addition to the cases mentioned under 1.4.1 engagement of the reverse gear will be prevented by the electronic control unit in spite of the depressed R push button of the push-button range selector in the following case. In this case, the R push button depressed will flash (see Section 1.1.2)

- Additional R push button on instrument panel not
depressed

1.5 Starting

After selecting the appropriate driving range, wait for approx. 1 to 2 seconds, then release the brake and accelerate.

Depending on vehicle configuration and loading state, the vehicle may start at low speed on a level track or on a slight uphill grade after release of the brake. If a lower driving speed is desired, this must be realized through operation of the brake pedal.

 **DANGER!**

- **In the event of reduced grip of the front wheels, e.g. due to black ice, locking of the front wheels may occur. The vehicle can then no longer be steered.**
 - **On major uphill grades, always accelerate with the parking brake activated**
Do not release the parking brake before you can feel propulsion. RISK OF ACCIDENT caused by vehicle rolling backwards!
 - **Fast rolling backwards in a forward gear, or rolling forward in the reverse gear, is not permitted and may result in stalling of the engine and loss of steering support.**
 - **Always start with great care and gentle acceleration when starting near persons or obstacles in order to rule out any risks.**
-

1.6 Downhill driving

Before driving down steep gradients, select driving range 1, 2, or 3 on the push-button speed range selector, as the situation may require. This limits upshifts.

 **DANGER!**

In an extreme case, the hold mode will be cancelled to protect the engine.
In such a case, the transmission may shift up to the highest gear irrespective of driving range selected.
RISK OF ACCIDENT!
Watch revmeter!

1.7 Change in direction of travel

Before changing from Forward to Reverse or vice versa:

- Bring the vehicle to a complete standstill.
- Depress push button "N" on the push-button range selector

Continue as described under Section 1.4


1.8 Kickdown (forced downshift)

To utilize maximum engine power, higher shift points can be realized via the kickdown switch (see illustration) or the CAN system (for acceleration or on uphill grades).

- Depress the accelerator pedal beyond the full-load action point (kickdown position).

NOTE

Use of the kickdown function increases fuel consumption.



1.9 Retarder operation

The retarder is a gear-dependent hydrodynamic brake which operates without wear. The retarder should be used for every braking action. This extends the life of the service brake. The retarder can be operated via a hand lever and/or the brake pedal.

When control takes place exclusively via the brake pedal, there is usually a rocker switch "Retarder ON/OFF" on the instrument panel.

In the event of manual-lever control, the lever must be returned to neutral position after each braking action.

Consult the vehicle operating instructions for more details on retarder control.

Conditions for retarder operation

Retarder operation is accepted by the electronic control unit only under the following conditions:

- Accelerator pedal in idling position
- A forward gear is engaged
- The driving speed exceeds approx. 3 km/h
- The ABS system is not active

If any one of these conditions is not fulfilled with the retarder engaged, the retarder will be deactivated.

When the maximally permitted oil temperature acc. to Section 1.1.2 is approached, the retarder's performance will be reduced or the retarder will be disabled by the electronic control unit.

**DANGER!****Risk of accident due to reduced braking power!**

The retarder must be deactivated using the "Retarder ON/OFF" switch in the following cases:

- On icy roads.
If an electronic braking system (EBS) and/or antilock system (ABS) is available, manual retarder shutdown is not required.
- When the permitted oil temperature acc. to Section 2.12 is exceeded.

Options for manually deactivating the retarder:

- Set the "Retarder ON/OFF" switch to the OFF position (if available)
- Set hand lever to zero position (if available)
- Depress pushbutton "N" on the pushbutton range selector and thus engage transmission neutral
CAUTION: Only in emergencies on black ice if there is no other option for switching off the retarder available.

1.10 Stopping, parking

Stopping

The vehicle can be stopped at any time through activation of the service brake, irrespective of the position of the push-button range selector. In such a case, the automatic electronic gearchange unit will engage the appropriate starting gear. Owing to the propulsion of the converter, the vehicle may come to a standstill on a slight grade even without actuation of the brake.

- Activate service or parking brake

In the event of a prolonged halt, the push-button selector should be set to the neutral position.



DANGER!

If the brake is not activated, the vehicle may start moving even without actuation of the accelerator pedal.

Transmission with function “Automatic Idle Shift” (AIS)

The automatic electronic gearchange unit will set the transmission to “Neutral” if the following conditions prevail simultaneously:

- Vehicle approaching standstill
- Service or parking brake activated
- Accelerator pedal in idling position

The range selected last on the push-button selector will be retained. As soon as one of the three conditions no longer prevails, the appropriate starting gear will be engaged.

Parking

- Activate the parking brake
- Then depress push button “N” on the push-button range selector



DANGER!

Before leaving the vehicle, always activate the parking brake. When the engine is switched off, there is no direct connection between engine and axle. The vehicle can start to roll!

1.11 Towing

1.11.1 Towing vehicle with coaxial transmission

1.11.1.1 Transmission is functioning

- Push-button range selector in Neutral position.
- Max. towing time: 2 hours.
- Max. towing speed:
Intercity and city buses: 25 km/h
Coaches: 35 km/h

NOTE

At an ambient temperature below -15°C , the maximally permitted towing speed is 5 km/h.

1.11.1.2 Transmission damage suspected

CAUTION

If transmission damage is suspected, the propshaft flange between transmission and drive shaft must be disconnected.

Exception: In a dangerous situation, towing without separation of the drive train is permitted until the vehicle has left the danger area (e.g. intersection, tunnel, etc.).

1.11.2 Towing vehicle with angle drive transmission

When a vehicle with angle drive transmission is towed, the propshaft between transmission and powered axle must always be disconnected.

Exception: In a dangerous situation, towing without separation of the drive train is permitted until the vehicle has left the danger area (e.g. intersection, tunnel, etc.). In such a case the following conditions apply:

- Push-button range selector in Neutral position.
- Max. towing time 10 minutes.
- Max. towing speed: 15 km/h

NOTE

At an ambient temperature below -15°C , the maximally permitted towing speed is 5 km/h.

1.12 Temperature monitoring

Transmission temperature monitoring is performed by the electronic control unit. Oil sump temperature and the oil temperature on the retarder output are sent to the vehicle computer via CAN. Depending on the vehicle application, alert signals will be issued when the permissible temperature limit values are exceeded.

Consult the vehicle operating instructions for more details.

When the permissible temperature limit values are approached during retarder operation, retarder performance will be reduced by the electronic control unit.

Action to be taken in the event of a temperature alert:

- Drive in partial-load range
- Using the "Retarder ON/OFF" switch:
Deactivate the retarder.

If this does NOT cause the oil temperature to drop:

- Stop the vehicle.
- Put push-button range selector in Neutral position.
- Run engine at raised idle speed.

NOTE

If, after a few seconds, the temperature does not decrease to the permitted range, this may be due to:

- Oil level too low or too high.
- Contaminated vehicle heat exchanger.
- Defective cooling circuit.
- Transmission damage

Inform ZF Service Center!

1.13 Status monitoring/warning lamps

The diagnostics system of the electronic control unit monitors the transmission status every time the vehicle system voltage is switched on and continuously while the vehicle is in motion.

Warning lamps

Faults are indicated by warning lamps lighting up (red or yellow) and/or by warning messages which appear on the driver's display panel (consult the vehicle operating Instructions).

If a selected driving range is not accepted by the ECU, the push button depressed on the push-button speed range

selector will flash (see Section 1.1.2)

1.14 Transmission response to a malfunction

To protect the transmission in the event of a malfunction, the following responses are provided:

Shift into Neutral:

In the event of serious malfunctions in the power supply to the transmission, e.g. short circuit.

Engagement of emergency operation mode

(see Section 1.14.1)

If there is an interruption of CAN communication or a loss of speed information.



DANGER!

The following applies in the event of a malfunction of the transmission system:

- **Serious risk of transmission damage**
- **Limited system monitoring**

RISK OF ACCIDENT!

- **Continuation of the trip is only allowed if the utmost care is practiced by driving as slowly and foresighted as possible.**
-

1.14.1 Emergency operation

Depending on the fault prevailing, the following limitations may occur during emergency operation:

- Retarder function limited or not available.
- Automatic Idle Shift (AIS) function not available.
- No activation of the engine brake.
- Torque converter lockup clutch (WK) open.
- Limitation of engine torque for transmission protection (no engine control).
- Poorer shifting quality or no gearchanges.

WABCO ABS BASIC INTRODUCTION

1. Introduction

Anti-lock Braking Systems (ABS) or - to use another common term - automatic anti-lock systems - are used to prevent a vehicle's wheel from locking as a result of excessive operation of the service brake, especially on a slippery road surface. Thus lateral control on the wheels being braked is maintained even at full brake application or in panic braking situations to ensure the cornering stability and steerability of a vehicle or a tractor-trailer combination to the greatest possible physical extent.

At the same time, the objective is to optimize the utilization of the available adhesion coefficient between tyres and the road surface and thus vehicle retardation and stopping distance.

High-performance ABS for commercial vehicles was first introduced at the end of 1981 by Mercedes-Benz and WABCO after elementary systems had been used in the USA from the mid 70s.

System design and control principles of this 4-channel system with individual wheel control (4 sensors - 4 modulators, called **4S/4M** below) were subsequently highly successful in the European market for commercial vehicles and became the basis for a world-wide standard for all commercial vehicles with power brakes.

ABS and ASR have proved their value as 4- and 6-channel systems in commercial vehicles. The reliability of systems and components from series production is excellent, in spite of their complexity. The de-

mand is rising not only in Germany and Europe or Israel and Australia, but also in the USA and in Japan.

As is generally known, the EEC and other legal requirements demand automatic anti-lock braking systems for certain types of commercial vehicles.

It is these provisions and measures which have resulted in the even more widespread use of ABS and in greater numbers being produced; this in turn has allowed cost reductions to be implemented, in spite of keen competition. WABCO has now developed the 4th generation of ABS and ABS/ASR. The D-generation offers different variants in the form of modular system designs.

These are based on state-of-the-art electronics technology with high-performance micro computers, including data storage, and take into account recent diagnostic principles. The 4- and 6-channel ABS/ASR systems for commercial vehicles offer various interfaces for working together with electronic engine control systems and the optimal use of an integrated speed limiting facility. Special functions for both ABS and ASR operation are available for selection in off-road operations.

This document describes the basic elements and the operation, the design and the system configurations of these anti-lock systems for commercial vehicles. The subject of drive-slip control (ASR) is mentioned only briefly in the section on system functions.

2. System functions

2.1 Description of an ABS control cycle

In case of impending wheel lock, the brake pressure of the corresponding wheel will be decreased, held during expected or measured wheel re-acceleration and subsequently increased in steps after re-acceleration. The cycle is started again if the brake force is still too high for the actual friction level (adhesion).

Rear axle wheels are subject to individual control (IR), front axle wheels are subject to **Modified Individual Regulation (MIR)**.

of the wheel. For this reason the brake pressure is quickly reduced and so wheel deceleration decreases. The time taken for wheel deceleration is determined by the hysteresis of the wheel brake and by the characteristic of the $\mu-\lambda$ slip curve in the unstable region.

Only after the wheel brake hysteresis has been overcome a continued reduction in pressure leads to a decrease in wheel deceleration.




Fig. 1

Fig. 1 shows an example of a control cycle with the most important control variables, wheel deceleration threshold $-b$, wheel acceleration threshold $+b$ and slip thresholds λ_1 and λ_2 .

As the brake pressure increases, the wheel is progressively decelerated. At point 1 wheel deceleration exceeds a value that can not physically be exceeded by vehicle deceleration. The reference speed, which up to this point had been the same as the wheel speed, now diverges and is reduced according to a fictitious vehicle retardation from point 2 (exceeding the $-b$ threshold) with a slower deceleration.

The deceleration threshold $-b$ is exceeded at point 2. The wheel now moves into the unstable region of the $\mu-\lambda$ slip curve at which point the wheel has reached its maximum braking force and any further increase in braking torque does not achieve any further deceleration of the vehicle but merely deceleration

At point 3 the wheel deceleration signal $-b$ drops below the threshold and the brake pressure is held at a constant level for a set time T_1 .

Normally, wheel acceleration will exceed the acceleration threshold $+b$ within this set time (point 4). As long as this threshold is exceeded, the brake pressure is kept constant. If (for example on a low-friction surface) the $+b$ signal is not generated within time T_1 , the brake pressure is further decreased by slip signal λ_1 . During this control phase the higher slip threshold λ_2 is not reached.

At point 5, the curve falls below the threshold $+b$. The wheel is now in the stable region of the $\mu-\lambda$ slip curve.

Brake pressure is now rapidly applied for time T_2 to overcome the brake hysteresis. The time T_2 is fixed for the first control cycle and then recalculated for each subsequent control cycle. After the initial rapid phase, brake pressure is then increased more gradually by "pulses", by alternating pressure hold and pressure increase.

The basic logic demonstrated in this example is not fixed at all; it adapts to the corresponding dynamic response of the wheel to varying coefficients of friction, i.e. it implements an adaptive type of system control.

All threshold values depend on several different parameters, such as driving speed, vehicle deceleration, etc.

The number of control cycles results from the dynamic response of the overall control system composed of the ABS-control - the wheel brake - the wheel - the road. Here, the frictional connection is of vital importance. In general, 3 to 5 cycles per second are performed, but significantly fewer on wet ice.

If an engine brake / retarder is used during an ABS control cycle, it is switched on or off by the ECU. For the purpose of front axle Modified Individual Control (MIR), the system compares the front wheel signals and modulates the pressure for both front wheel brakes. If, for example, control is activated on a front wheel

on a road surface with partially lower adhesion, the other wheel channel regulates the brake pressure so that pressure differences are built up (slowly, in graduated steps) to a limited maximum value.

In the event of a 4S/3M -or 6S/3M configuration being used, there is only one modulator on the front axle. The wheel locking first takes over ABS control of this axle. This results in a control process similar to Select Low which is called Modified Axle Control (**MAR**).

On 6x4 or 6x2 vehicles with a 6S/4M system, the same philosophy is used on the two rear wheels of one side which are controlled by one modulator. This type of system is called Modified Side Control (**MSR**).

2.1.1 Off-road ABS

The off-road mode can be used to allow more brake slip (temporary wheel lock) for braking on special surfaces. ECE R13 Supplement No.7 requires the off-road ABS function to be reset as soon as the ignition is switched on again.

The vehicle manufacturer decides, according to vehicle type and application, whether this switch is fitted or not. Off-Road ABS disables ABS control at vehicle speeds of less than 15 km/h and allows greater brake slip up to 40 km/h. At speeds above 40 km/h there is no modification to ABS control.

The mode selected is indicated to the driver by the warning lamp (WV) which will flash slowly unless other events result in a permanently lit warning lamp. The speed ranges and the warning light function can be altered via parameter settings. The vehicle manufacturer has to record in the driver's handbook that the off-road mode may not be used in ordinary road traffic because the vehicle might not meet the requirements of ECE 13 Cat.1 in these circumstances.

2.2 ASR

In addition to ABS control, trucks and buses can be equipped with an Anti Spin Regulation ASR, also known as drive-slip control. ASR reduces the amount of wheel spin (drive slip). The philosophy of ASR is based on keeping the slip of spinning drive wheels compared to the non-driven front wheels within a range providing the best possible traction and stability.

Depending on the road conditions ASR will start engine and/or brake control, if excessive wheel slip has been detected. On a homogeneous road surface, control is mainly achieved by reducing the speed of the engine, and differential brake control will be limited to synchronizing the wheels. If μ -split conditions apply, differential brake control will put pressure only to the brake cylinders of the wheel which is spinning. The engine torque is thus transferred to the other wheel.

Engine control will not commence until both wheels spin or the slip of the spinning wheel exceeds a certain threshold. During differential brake control, the pressure is supplied by way of actuation of the differential brake valve. The brake

pressure of the wheel which is spinning is controlled by the corresponding ABS solenoid control valve.

To prevent pressure building up in the brake chamber for the driving wheel which is not spinning, the ABS solenoid control valve of this wheel will cut off brake pressure. This cut-off function is also available for the Z-axis modulators of a 6-channel system or optionally for a separate solenoid valve in case of a 4-channel system on a 6x2 vehicle. To prevent the foundation brake from overheating, the differential brake threshold is subject to a linear increase at vehicle speeds over 35 km/h, thus increasingly controlling slip by means of slowing the engine speed. When the vehicle's speed exceeds 50 km/h, differential brake control will not commence although any brake control in process will continue.

ASR for 6x4 vehicles with a 6S/4M or 6S/6M system takes the speeds and accelerations of both wheels of one side into account. In comparison to a 4S/4M system, this system is able to avoid spinning or locking of the driving wheels which have no sensors.

2.2.1 Traction mode

In deep snow or comparable conditions the traction can be increased by activating a special mode. By temporarily pushing the traction mode button for at least 150 milliseconds, the ECU switches to a type of ASR control with different thresholds and different engine/differential

brake distribution to allow higher slip ratios. Depending on the parameters set on the ECU, an ordinary switch may be used for this purpose. Activation of the ASR traction mode is confirmed by slow flashing of the ASR lamp to inform the driver that vehicle's stability might be impaired.

2.3 Speed limiter with proportional valve

The auxiliary output can be used for limiting the speed using a proportional valve and an ASR operating cylinder. These components actuate an injection pump and consequently modulate the speed of the vehicle.

An idle stop cylinder is needed for certain single-lever injection pumps.

The speed limiter meets ECE requirements. The speed limiting value is part of the parameter record and is stored in the EEPROM. The standard parameter record has a default speed limiting value set to 160 km/h

This value can be changed via the diagnostic interface. The minimum

value is 20 km/h For vehicles with non-synchronized gearboxes, the neutral position has to be allocated to the related input or additional equipment is necessary.

A second speed limiting value can be defined as part of the procedure for setting the parameters (lowest speed setting). When the speed setting switch is actuated, the current speed is stored and compared to the parameter value for the speed setting. The vehicle's speed is limited to the higher of the two values as long as the speed setting switch is actuated.

The signal from a tachograph which is connected to the C3/B7 input port

is required to give off between 2,400 and 24,000 pulses per kilometre. Suitable appliances are, for instance, the KIENZLE tachographs 1314 or 1318.

The ECU checks the input signal for plausibility and signalling errors. Any error is indicated by the warning lamp or ASR lamp if the vehicle is moving at a speed faster than 3 km/h

If no C3 signal is available, the wheel speed signals from the ABS/ASR system are used to limit the speed (does not comply with EC regulations!).

ECAS System Introduction (for tourist bus use)

1. System introduction

The name ECAS stands for Electronically Controlled Air Suspension.

ECAS is an electronically controlled air suspension system with a large number of functions.

Air suspension systems have been used in motor vehicles since the mid 50s especially in buses. Air suspension systems are used in them as a standard and are increasingly being used in trucks and trailers. The advantages of air suspension over mechanical suspension (steel springs) are listed below:

- * Increase in ride comfort due to lower spring rate and low natural frequency
- * constant vehicle height irrespective of the load
- * precise load-dependent activation of the brakes through use of the air bellows pressure as control pressure for the proportioning valve
- * Kneeling function (lowering of one side of the vehicle to facilitate entry and exit)

The control system was initially designed with pure mechanically operating leveling valves, soon afterwards electromechanical control systems were developed. This served to enhance ease of operation and to facilitate raising/lowering processes.

ECAS is the most advanced development in this direction. Using electronic control units enabled decisive improvements in the conventional system; it enabled many functions for the first time ever:

- * Reduction of the air consumption none while the vehicle is moving. Air savings of approximately 25 % were determined using ECAS compared to a conventional air suspension system in low-floor buses for scheduled route services.
- * High speed of all control processes due to large valve cross-sections (nominal size 7 per air bellows).
- * Easy installation. Only one air line is required from the solenoid valve block to each bellows and one to the storage tank.
- * Raising/ lowering function and kneeling conform to the legal requirements
- * High system flexibility for different kneeling types
- * Extensive safety concept, error storage and diagnostics capabilities.

In mechanically controlled air suspension systems, the device that measures the level also controls the air spring. With ECAS, an electronic system takes over

control, regulating the air springs by means of solenoid valves informed by measured values from sensors.

Apart from controlling the normal level, the electronic unit also covers control of the other functions: working together with control switches and sensors for the tyre deflection compensation, the ECU achieve this without the need for numerous additional valves required by conventional air suspension control.

ECAS at different configuration levels can be fitted in various bus types.

The ECAS system in a bus consists of the following components:

- * an ECAS electronic unit (ECU)
- * a solenoid valve (solo vehicle)
- * 3 distance sensors
- * optionally 1 pressure sensor
- * Operating switches
- * Sidewalk detector




Abb. Example ECAS base system

- 1 ECU (electronics)
- 2 Distance sensor
- 3 Solenoid valve
- 4 Air-suspension bellows
- 5 Distance body/axle

ECAS with CAN bus

The most recent generation of the ECAS systems has CAN bus capability. Here the electronic systems are networked by means of a CAN bus and information is transmitted via SAE-CAN identifiers.

The CAN Bus (Controller Area Network) is a serial databus system, which was developed for networking controllers in automobiles with the aim to reduce cable harnesses. Instead of using an electrical circuit for each transmitted signal, the 'bus' is based on a communication platform which regulates the relaying of messages between several devices.

The Flexibly Programmable Controls serve as an interface to provide each individual system a precise process I/O image, i.e. information on the inputs and outputs in the overall system, via a CAN data bus.

One of these SUB-CAN BUS systems is the CAN-BUS 'IES'. The ENR (ECAS) and various other systems, such as the electronic brake system EBS, are currently connected to it.

The systems are connected to their sub-systems via a system bus. The ECAS system is integrated in a vehicle system based on the CAN-BUS to ISO 11898.

The electronics provide the connection with the vehicle electrics via a CAN data bus and via separate inputs and outputs.

When this highly standardised technology was introduced, the vehicle manufacturers specified that the system suppliers are responsible for the systems.

2.1 System configuration

ECAS has a modular structure to ensure that different vehicle types can be equipped with the system. The choice of system components to be used is determined by what is required of the system.

With the most basic configuration level, only one axle is equipped with the ECAS air suspension and only one height sensor monitors the body height. With this configuration, the support bellows of a tandem axle can be interconnected.

However, if the body is to be kept parallel to the axle even when the load is distributed unevenly in the vehicle, it is necessary to arrange distance sensors on both sides and to control the support bellows of the axle or tandem axle by separate solenoid valves.

A vehicle with full air suspension is usually equipped with three distance sensors. The front axle, for example, has one distance sensor and the rear axle has two in this configuration.

Vehicles are also equipped with four distance sensors however. This applies mainly to vehicles with independent wheel suspension. With two front distance sensors it is possible to implement cornering detection and ESAC. The mean value from the two distance sensor signals is used for ECAS control.

The two bellows of the axes with only one distance sensor are interconnected by a restrictor to enable pressure equalisation. During brief changes in the direction of travel however, this restrictor prevents rapid pressure equalisation. This prevents exhaust of the bellows on the outermost side of the curve, thereby reducing tilt of the vehicle against the curve direction. If cornering is detected, automatic level correction is interrupted or is not started. This prevents correction of any rolling movements of the vehicle body occurring at this moment. The transverse restrictor is deactivated analogous to deactivation during kneeling. Calculation of this lateral acceleration is based on the front wheel speed information that is transmitted from the EBS to the ECAS-ECU via the CAN-BUS.

In an articulated bus the axle of the trailer section is equipped with two additional distance sensors and its own control electronics.

A further breakdown of possible system configurations, illustrated by a circuit diagram and part numbers, is provided in the appendix.

Pressure test connections

The support bellows should be fitted with pressure test connections so that the control pressure of the LSV can be measured when testing the braking system.

These test connections also provide a makeshift solution for filling the support bellows in the event of a fault in the air suspension system. With the assistance of a tyre inflation hose, the vehicle can usually be driven to the workshop under its own power.

3. System function

Although ECAS offers a wide range of functions, not all of them need to be implemented in any given system. The respective vehicle manufacturer is responsible for the system configuration and for setting all the parameters, both of which must never be changed without prior consent from the manufacturer.

3.1 Functions of the ECAS-ECU

3.1.1 Controlling the nominal level

Nominal level control is the basic function of ECAS. The continuous comparison of the actual values supplied by the distance sensors with the nominal values stored in the ECU keeps ECAS permanently informed of the vehicle's current ride height. If deviations exceed a certain tolerance range, solenoid valves are triggered and the actual level is adjusted to the nominal level by means of air intake or air exhaust of the air suspension bellows.

Unlike with conventional air suspension, the ride height is not only adjusted to the vehicle's normal level but any other preselected level. This means any level level that was set is maintained regardless of the number of passengers who get on or off the bus.

In the event of greater level changes, the solenoid valves are pulsed (CAN II), shortly before the nominal level is reached, relative to the lifting speed and the distance to nominal level in order to prevent overshooting.

All control processes can be executed in parallel on the different axles (front and rear axle simultaneously) within the tolerance limits.

3.1.2 Normal level 1/2/3

Normal level 1 is the level that was defined by the vehicle manufacturer for normal driving. The normal level 1 determines the ride comfort, road safety and body height, which must comply with the legally prescribed limits.

Normal level 2 is level that deviates from normal level 1 as an adjustment to special driving conditions. Speed-dependent adjustment to this level is also possible. The height of normal level 2 is permanently defined by a set value (parameter) in the electronic unit. A switch is used to choose between normal level 1 and normal level 2.

For safety reasons, it is possible to automatically adjust the level to normal level 1 as soon as the vehicle exceeds a certain speed threshold (20 km/h for example); the level is then readjusted to the previous level once the speed drops below a lower speed threshold (10 km/h for

example).




Abb. Illustration of the ride height

Special aspects with regard to CAN II electronic systems

- CAN II electronic systems also permit setting parameters for normal level 3 as a speed-dependent level
- Customer Level: Independent parameters can be set for levels on rear axle left and rear axle right.
- All levels are obtained via CAN identifier ASC2 ...

Manual level adjustment using switches/ pushbuttons

In certain cases it may be necessary to set a certain level which differs from normal levels 1/2. Pushbuttons can be used for lifting and lowering. When these are actuated, the bus is raised or lowered at the selected axle(s) by means of a preselector switch.

Height limitation

The electronic unit automatically discontinues height limitation when programmed (calibrated) values for the upper or lower limit positions are reached.

3.1.3 Kneeling

Kneeling is a special function for buses. The regulations for kneeling systems are described in section 35d of the StVZO (road traffic regulations). Kneeling describes a process whereby the bus is lowered to make it easier for passengers to get on and off. Depending on the parameter settings of the electronic control unit, this can take place towards on one side on both axles at the axle with one distance sensor (usually the front axle). ECAS provides the option to take the door position into account and to safeguard the lowering process by means of a contact strip that is monitored by ECAS. If the contact strip reads during a kneeling process, the bus reverts to normal level.

Diverse kneeling function actuation types are possible depending on the electric wiring and the parameter settings of the electronic unit.

Supply pressure monitoring

One precondition for kneeling is the availability of sufficient supply pressure to quickly raise a lowered and fully laden vehicle back to normal level. If the supply pressure has dropped below a value monitored by a pressure switch, ECAS will not permit kneeling in order not to prolong the time spent at bus stops.

Open/close the passenger door.

1. Before leaving the vehicle, press the button 1 of the door remote controller to close the door.

1



2

2. Use the key to lock the door. First insert key into the hole 3 and clockwise rotate key about 90°, then anticlockwise rotate handle 4, after that the door would be locked.



3

4

3. If need open the passage door, insert key into the hole 3 and clockwise rotate it about 90°, then clockwise rotate handle 4, follow press the button 2, after that the door would be opened.

Appendix:

The following are all type of door lock and door remote controller of King-Long.



Lock1



Lock 2



Lock 3



Door remote controller 2



Door remote controller 1

Door emergency switch

The model 1 door emergency switch is located on right upside of the ingress.

The model 2 door emergency switch is located on right underside of the ingress

The model 3 door emergency switch is located inside the door pump cover which is on the top of the door.

Please rotate the switch and throw open the door in emergency.

Special attention: The door emergency switch is only used in the emergency mode. Please don't rotate the door emergency switch in driving for fear of danger.

Model 1



Model 2



Model 3



Adjustment of the driver's seat

The driver's seat may be made proper adjustment for the back and forth as well as the backrest angle according to requirement of the driver.

Handle 1 and Handle 2: cushion height adjustment

Handle 4: back and forth adjustment

Handle 3: adjustment of the driver's weight

Left handle: backrest angle adjustment

Note: Number of handles varies with vehicle model

Attention!

The seat should not be adjusted during driving to ensure driving safety.

Adjust the driver seat only when the vehicle is stopped and the parking brake is on.



Horn button

It is on the steering wheel. The horn is hooting when pressing the button 1.

The type of steering wheel may vary with vehicle model. Please use the horn only when strictly necessary to warn other drivers and pedestrians.

Model 1



Model 2



Adjustment of the steering wheel



Pull-up the loosening handle 1 or rotate the loosening button 2. Adjust the height and the inclination of the steering wheel to the desired position. After adjusting, press the regulating handle or button down to lock the steering column.

Note: Number of handles varies with vehicle model

Attention!

Adjust the steering wheel only when the vehicle is stopped and the parking brake is on.

After adjusting, press the regulating handle or button down to lock the steering column.



Ignition switch

Position of the ignition key is shown in fig.1.

- 1."L" LOCK: Insert or remove the key in this position.
- 2."A" ACC: Power supply of the instrument is switched on
- 3."O" ON: Normal driving position
- 4."S" START: Initiating position of the engine, and the key may rebound to the "ON" position automatically after the startup.


Before starting the engine, turn the key to the "ACC" position and then to the "ON" position. At this point, three lights (red, yellow and green) on the dashboard will come on. Wait for the lights to go out completely before you start the engine. However, make sure that all of the self-check lights have gone out completely before starting the engine. Allow the engine to run at idle speed for three to five minutes after it has been started; but never let it run for more than 10 minutes at idle speed. If the vehicle does not move, increase the fuel to the accelerator modestly to increase the rotational speed of the engine a little; this will also prevent the early wear and tear of the engine.

Note:

1. Turn the ignition key to the OFF position after the engine has been turned off and has stopped running.
2. If the first attempt to start the engine is not successful, please wait two minutes before trying again.
3. If the engine fails to start after three attempts, check the fuel supply system. If the vehicle runs on natural gas, check the gas supply system.

Attention!

1. Do not remove the ignition key while the vehicle is in movement. And the ignition key should be turned to the LOCK position only after the engine shut down.
2. When leaving the vehicle, even for a short period, take the key out to avoid operation of the vehicle by children or unauthorized persons.



Lamplight operating handles

Model 1

The lamplight operating handle is located on left underside of the steering wheel, which control the front small light, headlamp, headlamp dimming, etc

OFF Indicating that the headlamp and the small lamp are all off.



Is the small lamp indication. The small lamp, the instrument light and the side indicator lamp will all be turned on when anti-clockwise rotating the handle to position of this identification.

☰☐: Is the headlamp indication. The headlamp, small lamp, meter lamp and width lamp will all be turned on when continuously anti-clockwise rotating the handle to position of this identification.



Is the turning indication. By up and down motions of the operating handle may control the left and right turning lamp and that on the dashboard.



Is dimming indication. Back and forth the operating handle gently may actuate the headlamp dimming.

Note:

It's important to dip the lights promptly when approaching an upcoming vehicle in order to avoid dazzling its driver with the high beam of the headlight.



Model 2



Wiper operating handle

The wiper operating handle is located on right underside of the steering wheel. (model 1~2)

OFF Out of work

INT interval wiper operation step

LO Slow wiping

HI Quick wiping

Model 1 (with retarder)



Model 2 (with exhaust brake)



The wiper may spray water by pressing the end of the handle.


The shifts of the retarder may be converted by up and down motion of the handle.

Note: do not actuate the wiper without water; press the washer button as needed, then actuate the wiper.


Passenger control panel instruction

1. air outlet
2. service button
3. reading lamp button
4. lamp
5. loudhailer
6. stop button


Model 1



Model 2



Model 3



Safety hatch

The safety hatch is located on scaffold of the vehicle. Please open the safety hatch according to the above diagrammatic representation and illustration for escaping in case of danger.

Model 1



Model 3



Model 4



When in emergency and dangerous condition, should

- 1) push upward with hands and make the hatch open
- 2) pull down the plastic cover and rotate red handle
- 3) push dome open
- 4) exit through hatch

Model 2



Safety hammer

The safety hammer is located on the side window.
Please take down the safety hammer and break open
the safety window for escaping in case of danger.

Model 1



Model 2



Model 3




Relays & Fuses

The Relays & Fuses Box always installed in the compartment of the instrument desk or a tool cabin belong to front right side panel.

The box integrates 50 chip-type fuses, 20 general and special relays, and has 8 standby chip type fuses, one fuse clip, which makes its construction more compact and function more powerful. It improves design of the past Relays & Fuses Box , therefore it avoids weakness such as unreliability and short service life, it applies integrated circuit and designs 5 special relays: intermittent wiper relay, turning flasher relay, lower water level warning controller relay, monitor power relay, brake light failure warning relay (when power supply voltage is lower than 23V, power supply of acoustic set and monitor is cut off and will be begin to work again after power supply voltage resumes to normal).

Installation Position




The vehicle installed the Relays & Fuses Box in the compartment of instrument desk.




The position of Management Module, CAN Processor Module, and the Relays & Fuses Box

They are located in the compartment of instrument desk. When servicing, may open the desk cabin gate

Switch control box (Model: CQ2025)



CQ2025 A wiring diagram (Printed on opposite cover of the switch control box)



**Preparative for vehicle operation start up:
Check daily, before turning engine on:**

1. Check oil level of the engine

The warning “Engine oil pressure” is displayed as a signal item on the combination instrument when the oil pressure is too low, the alarm buzzer sounds, the warning light STOP comes on, stop the engine and check engine oil level at the dipstick. Provide immediately for the oil replenishment to its correct level.

The oil level should always be checked with the vehicle parked on level ground, before starting the engine up, or at least 5 minutes after having shut it down.

Open the engine compartment hood.

Take out the oil dipstick, and clean it with a clean cloth without loose threads, and put it back into its place fitting it in completely.

Once again pull out the dipstick and check the oil level.

- a. The oil should not exceed the maximum level.. drain the excess.
- b. If the oil is at operational level, do not add more oil to the crankcase.
- c. If the oil is at or below the minimum level, add the same type and brand of oil to the crankcase as that already there, until reaching the maximum level..


After the checking, replace and fit the dipstick completely back into its place.

If the oil level is checked after the engine has been run for a period of time, then it should take at least five minutes before the measure to ensure the oil back flow to the oil sump in full.

Oil level dipstick



Oil inlet



2 Check level of the coolant

The coolant level is automatically monitored.

If coolant level gets too low, the digital indicator displays a driver information on the combination instrument. In this case, park vehicle in a safe place as traffic conditions permit, stop engine and visually check the coolant level.

Check the coolant level only when the engine doesn't work and its temperature is below 50°C.

The anti-freezing rust-inhibiting engine coolant level can be observed from the observe pipe.

The coolant level should be between the maximum level (MAX.) and minimum (MIN.) level indicators in the compensation tank.

If it is necessary to add coolant to the system:


- a. Place the heating system command in the position of maximum heating potency.
- b. Add the coolant to the system up until the maximum level indication. Only use coolant which is recommended.
- c. The compensation tank cover should not be opened when temperature of the coolant is still high to avoid being scalded Place the lid on the system and turn it to the limit.
- d. Pressure valve of the compensation tank should be opened when adding the coolant to eliminate air in coolant pipeline of the diesel engine.
- e. Run the engine for a short time at varied rotations.
- f. Stop the engine and check the coolant level.

If necessary add more coolant to the system

Anti-freeze and antirust solution (mixture of glycol and water) should be added to cooling system from time to time to avoid sediment, frost, oxidation and increase boiling point.

Note: When adding coolant, please choose the same model to avoid sediment. If coolant is degenerative, replace it immediately.

Coolant specification as shown below: users should choose products produced by normal factories according to requirement



Observe pipe



Observe pipe



3 Fuel pre-filter with water separator (drain accumulated water)

Draining accumulated water

On a daily basis, check the lower cup of the water separator. If there is water in the cup, unscrew the draining plug one or two turns, to drain the accumulated water.

After draining the water, tighten the draining plug correctly.

When the accumulation of impurities in the lower cup is noticed, take the vehicle to a workshop to carry out its cleaning.

Changing the fuel pre-filtering element

The fuel filtering element should be changed periodically, at the intervals recommended in the maintenance manual.

If however, the filtering element is easily saturated needing substitution at very short intervals, this is an indication of the accumulation of impurities in the interior of the fuel tank, and the cleaning of the latter should be carried out.

In order to change the fuel filter element, take the vehicle to a Dealer or a King-Long Workshop.

Fuel system discharge


Activate the manual pump until feeling resistance on pumping.

Start up the engine without accelerating. If the engine does not start running in 20 seconds, interrupt the startup and wait at least one minute before trying again.

If the engine insists on not working, repeat the discharge operation.

Leave the engine running for about a minute to completely eliminate the air from the system by way of the auto-discharge system.

In order to reduce environment pollution problems, do not drain the residues accumulated in the water separator directly into Nature (rivers, lakes or soil). The drained residues should be collected in appropriate containers and taken to receiving centers to have proper final destination (see local legislation).



Release valve



Manual pump

Model for Euro III IV

4. Fuel level

Turn the ignition key to drive position (on).


Check the fuel level on the indicator. If necessary, fill up the fuel tank. (But direct viewing by open the tank cover is preferred).

Eliminate deposite water in diesel filter in time and check fuel pipe for no leakage. Ensure sealing performance of fuel tank , and wipe up dirt before opening fuel tank.

Before filling up, shut down engine.

Do not drive vehicle in empty fuel tank. When the fuel level indicator is on the red bar, refuel the vehicle to avoid air entering the fuel system.

Fill the fuel tank only with good quality fuel free of contaminants. The fuel might as well be filled up when running in the humid area to avoid inner rustiness.



5. Vehicle lighting, intermittent lights and brake lights

Check all instruments and indicator lamps for normal, especially the head lamp, the turning lamp, the brake lamp, the reversing lamp and the danger alarm lamp.

Check the bulb and the switch for their damage. To carry out the lamp substitution, hands should be very clean. If possible handle new lamps with tissue paper.

Clean the external of all instruments and indicator lamps to ensure clear indication.

Attention!

The traffic laws regulate the location, lighting intensity, and color of the lenses and the quantity of lanterns for each type of vehicle. The King-Long vehicles leave the factory in strict obedience of these specifications. Traffic safety depends on these factors; therefore do not change the place of the lanterns. Substitute the damaged lanterns only for other original ones. Remember that a change of lantern colors can confuse other motorists and result in serious accidents. Avoid unnecessary lantern adaptations. When substituting lamps, use the same type and potency as the original lamps. Do not carry out any lamp adaptation in the headlights, as this will affect their adjustment and performance, putting the vehicle traffic safety at risk.

On a regular basis revise the illumination system, keeping it always in perfect working conditions

6. Check the level of AdBlue and the daily maintenance of SCR system

(1) Check the level of AdBlue.

When the vehicle key rotate the ON position, the LED screen of combination instrument will display the remain volume of the AdBlue, please see the right diagram.

The volume of AdBlue



The AdBlue consumption is 5 percent of the fuel consumption. If the remain volume of AdBlue is less than 12%, the lamp 1 will flash and you need add AdBlue. If the remain volume of AdBlue is less than 6%, this lamp will light and the power of engine will be declined forcibly. This will cause the emission substandard and it is not good to engine.



(2) The daily maintenance of SCR system



Please add the AdBlue when it is insufficiency. Ensure the AdBlue meet the requirement. Check the SCR system is well enough and has no leaking before driving. There is obvious add mark in AdBlue tank. If add substandard AdBlue, must stop the vehicle right now and clean the AdBlue tank, re-filling the qualified AdBlue. The air filter should be clean and replace regularly.

Special attention:

If the AdBlue spill in skin, mild irritation may occur. Wash off with soap and water. If the AdBlue spill in eye, irrigate eyes with large amount of water. The AdBlue is Non-combustible, if heated water evaporates and ammonia will be released.

7. Drain water in air tank

Open the water drain valve of air tank to drain oily water fully. If too much oily water is bled, check to see if desiccant needs to be replaced in air drier. (This may be avoided when adopting the automatic drain valve but it should be checked every two weeks)

Check daily after turning engine on:

1. engine oil pressure

Run the engine.

The information on engine oil pressure can be requested through the driver information digital display.

If the oil pressure is too low, the oil pressure is automatically shown on the combination instrument.

Indication of the oil gauge will show a high value after the cold start of the engine and then it should be kept within the range of 0.07-0.52Mpa (0.7-5.2kg/cm²) along with the increment of the oil temperature as well as the normal engine speed.

2. Pneumatic pressure

The air pressure gauge indicates the reserve pressure individually for the front and rear service brake circuits.

The reserve air pressure in each brake circuit must be sufficient for the correct operation of the brake system.

The STOP warning light comes on in case of low brake pressure in the service brake circuits.

Attention!

If the driver information indicator displays the warning “brake pressure” and the STOP warning light comes on with the engine running, it will be an indication that the air pressure is excessively low. Do not drive the vehicle if the air pressure gauge displays low air pressure in one or both brake circuits, as the service brake could fail to result in serious accident.

3. Tachometer working order

Indications on tachometer scale:

- Green zone – operating range of maximum performance
- Yellow zone – a little high speed range (warning of engine overspeed)
- Red zone – engine overspeed range (risk of immediate engine damage)



Always observe tachometer while driving the vehicle.

Whenever possible keep engine running within the economical range. (green zone)

On downgrade, select an adequate gearbox speed and monitor vehicle speed to avoid engine operating in the danger range (red zone).

When the exhaust-brake is operating on down grades, select an adequate gearbox speed to keep engine speed within efficient exhaust-brake operation (yellow zone) .

Always avoid engine over revving (red zone), as engine operation in this speed range can give rise to a immediate engine damage or seriously jeopardize its durability.

The yellow range with red reticle can be used occasionally when the exhaust-brake needs to be used at its efficiency limit, however, at risk of engine durability. Therefore, do not operate in this range in a normal or usual way.


4. Steering play

Steering wheel play

Run the engine at idle gear and straighten the front wheels forwards.

Turn the steering wheel alternatively to the right and to the left.

The steering play (free movement of the steering wheel) is measured on the perimeter of the steering wheel and should be between 20 and 30 mm.



Control periodically, at least once a week:

1. Check tire for abrasion and pressure and tire nut for fixture

The vehicle's safety and performance depend considerably on the state of the tires, reason why they should be checked daily.

Before driving a vehicle, check charging pressure of tire for normal, tire for damage, tire nut for fixture.

Note: At initial 50km, please tighten tire nuts of new vehicle to specified torque in appendix.

Tire pressure

Keep the tires always correctly calibrated. The inflation pressure should be checked with the tires cold at least once a week.

After driving the vehicle for some time, the tires heat and in consequence of the heat, the inflation pressure increases. Never, under any circumstance, empty heated tires to reestablish the recommended inflation pressure.

The pressure difference between the assemble tires on the same axle should not be superior to 0.1 bar.

Wheel hubs

Keep them always clean, eliminating eventual mud or other dirt adherence. Substitute the damaged and/or deformed hubs. The utilization of refurbished hubs is not recommended.

Wheel nut

Without fail re-tighten the wheel fastening nuts of new vehicles after running 50km.

The wheel fastening nuts should be retightened, crosswise, in turns, observing the recommended tightening torque according to the type of fastening nut. If a torque meter is not available, tighten the nuts strongly, using the vehicle tools without additional levers.


2. Air cleaner (activate the dust discharge valve to loosen accumulated dust)

The maintenance of the air cleaner is made up of the substitution of the filtering elements and should be done only when the maintenance indicator indicates the saturation of the element.

The cleaning of the main and safety filtering elements is not recommended. The re-utilization of the filtering elements can result in deficient filtering of the air and cause serious damage to the engine.

When washing the engine, conveniently protect the air inlet with a plastic or similar material to avoid the infiltration of water to the air filtering element. After washing the engine, remove the protection from the air inlet.


Model I



Periodically press the dust discharge valve with your hand, in order to incomplete the dust which possibly be caught in the internal part maintaining them clear. At the same time, check clip connecting rubber hose of air intake system with steel tube in case of dust entering air intake system due to looseness and decrease in engine life.

The air cleaner restriction is electronically controlled. If the indication of saturated air cleaner appears in the display of digital indicator in combination instrument, send the vehicle to a King-Long Dealer or authorized workshop to inspect and clean the air intake system and substitute the main filtering element.

Model II



1 automatic dust discharge valve

Indication

The main filtering element of the air filter should be substitutes after maximum 2 years use.

The safety filtering element (optional) should be changed at every third main filtering element substitution, or after maximum 2 years of use.

3. General leakages (water, oil, fluids and fuel)

Check the engine, the transmission, the driving axle, the steering system, the cooling system and the oil pipeline, the air pipeline of the complete vehicle for their leakage.

4. Fastening and state of seat belts

Check buckle of the safety belt of the driver seat for normal and ensure for its lockup under the following situations when fastening the safety belt.


- The body dashes forward all of a sudden;
- The vehicle makes an emergency braking or an abrupt acceleration;

5. Check emergency devices and driver's tools

Such as extinguisher, crosstie for blocking vehicle, emergency hammer, jack and etc..

Fire extinguisher:

The pulse super-micro powder fire extinguisher is fixed in the engine compartment, when the compartment is on fire, the fire extinguisher activate automatically or is active by manual work to eradicate the fire



The fire button is usually located at auxiliary instrument desk in the driver compartment where people could operate it easily.


Operation: 1. When the engine compartment caught fire, the driver should stop vehicle and switch off engine immediately, open the fire button cover, and press the fire button, start-up fire extinguisher



2. Fire extinguisher may start-up automatically when it catches fire or its temperature arrives at **170°C**.

Important hint:

1. Fire extinguisher can be used for one time only, DO NOT press the fire button except for emergency condition.
2. The fire extinguisher can not start-up by press the fire button manually if the vehicle battery is dead or power turn off.
3. If the vehicle needs to be repaired, you could take away the anode and the cathode. And put them back after the reparation completed.



Inner fire extinguisher is fixed under the passenger's chair, when vehicle caught fire, stop vehicle and use the fire extinguisher.



6. Working order of windshield wipers and conditions of wiper blades and arms

Regularly check the windshield wiper blades for dirt or damage.
Press the lever to activate the windshield washer

Caution: Do not use the windshield wipers when the windshield is dry. Before activating the wipers, push the head of the wiper lever inward to spray detergent onto the windshield.

Check surplus of detergent

Stop vehicle on a flat road, open side cover of instrument desk.
Container of detergent is located inside instrument desk. If detergent is insufficient, add.

Add the clean water into the tank for windshield washer.

There are 2 kinds of water tank.

Model 1



Model 2



7. Electrical rearview mirror

Check, adjust and clean the rearview mirror.

Rearview mirror control button

Model 1

L: adjusting left rearview mirror.

R: adjusting right rearview mirror.

Mirror button: push down the arrow headed button to adjust the mirror for 4 directions.

Model 1



Model 2

Model 2

L: adjusting left rearview mirror.

R: adjusting right rearview mirror.

Mirror button: rotate the handle to adjust the mirror for 4 directions.



Model 3



Inspection every two weeks before and after driving**Power steering**

Ensure that all the maintenance service jobs on the steering system be carried out at the intervals recommended in the maintenance manual to guaranty total efficiency and safety.

If any working abnormality in the steering is noticed, immediately supply the necessary repairs.

The habits of forcing the steering too far against wheel obstacles and of activating the steering while the vehicle is stopped are harmful to the steering system and should be avoided.

In emergencies, in the case of damage to the power steering system, the steering may be used without hydraulic help, however, in this condition there will be more steering wheel play and the steering will become noticeably “heavier”. Drive the vehicle very carefully and take it to an authorized King-Long Dealer or Workshop to re-establish the correct working order of the steering system.

Important: In the case of damage to the hydraulic steering pump or of the total loss of fluid from the hydraulic system, we recommend that the vehicle is not driven further than 50KM in order to avoid further damage to the steering system components.

Power steering fluid level

The power steering fluid level should be checked while the engine is running at idle and the fluid is hot. Run the engine at idle gear and turn the steering from side to side various times to heat the steering system fluid.

Check the level through the inspect window of the container.

Model 1



Model 2



Model 3



General state and tension of drive belts

Check the tension of engine belt, fan belt and compressor belt, if loose, tension it; if damaged, replace it. Do not start up the engine without the drive belts. In the case of one of the belts breaking, immediately stop the engine and have a new belt put in.

The checking, adjustment or substitution of the drive belts should be carried out with the engine shut down.

Check cross plane of the belt for no cracks. Crackle in the transverse direction (along the belt width direction) is acceptable while that in longitudinal direction and transverse crack cross is unacceptable. Please replace the strap in case of abrasion or chip dropping off.

Too tight or too loose belt would make against proper operation of engine. Press belt to check tension.

Please refer to the manual book of engine assembly for detailed adjusting method and tension of belt.

The poli-V belts demand technical knowledge, therefore we recommend that this job, when necessary, be carried out at a King-Long authorized Dealer or Workshop.


Fan drive belts

If it is necessary to replace the fan drive belts in emergency situations, adjust their tension in such a way that upon pressing them with one's thumb in the middle of the distance between the pulleys, a deflection of approximately 20mm is observed. Loosen fastening nut of intermediary pulley before turning the adjusting bolt. After adjusting fan belt tension, tighten the fastening nut of intermediary pulley firmly.

Model 1:

Adjusting method of the single belt driving fan belt is shown in the figure


1. Check tension of belt
Apply force of 98N by the finger.
Strap sinkage between the crank pulley 1 and the fan pulley 2 should be 15 ~ 20mm.
2. Adjust tension of cone belt
Adjust bolt 3 until the tension is proper.
The max offset angle of the fan pulley shaft should not exceed 5°, or else please replace it.



Model 2:

Adjusting method of the fan belt is shown in the figure

1. Check tension of belt
Apply force of 98N by the finger.
Strap sinkage between the crank pulley 4 and the counter pulley 2 should be 10-12mm.
Strap sinkage between the counter pulley 2 and the fan pulley 1 should be 7 ~ 8mm.
2. Adjust tension of cone belt
Adjust bolt 3 and counter pulley 2 up and down until the tension is proper.



Air conditioning compressor drive belt

The pneumatic tensioning system keeps the tension of air conditioning compressor drive belt correctly adjusted and do not need to be adjusted periodically.

Adjusting method of the air conditioner belt is shown in the figure


1 Check tension of belt

Apply 98N force to belt with finger

Belt crank pulley 4 and middle pulley 2 should lower 10~12mm

2. Adjust tension of cone belt

Adjust nut 1 until tension of belt is proper



Check level of battery electrolyte

Open the battery cover to check level of electrolyte, if the level is lower than scale marked on the battery, please add it in time.

Note: During adding electrolyte, never start engine.

Battery

The battery compartment is located at the second compartment of left or right rear side.

- 1 battery
- 2 switch control box
- 3 main power switch



To access the battery , open the switch control box panel.

After the vehicle has finished a day's work, the main power switch should be turned off.

Cleaning

Keep the batteries always externally clean and the air vent unobstructed. Avoid battery contact with petroleum derived products.

Charge

Do not allow batteries to maintain a charge inferior to 75% of the total charge.

Do not submit the batteries to excessive overcharges of discharges.

Engine start up and shut down

Procedures for engine start up

Activate parking brake.

Place the gear box lever in neutral. Start up is not possible in gear position.

Turn the ignition key into start position.

Start up without stepping on the accelerator. If the engine does not work after about 20 seconds, interrupt the start up process and wait at least 15 seconds before activating start again. To repeat start up, it is necessary to turn the key back to the off position.

Let the ignition key loose as soon as the engine starts running.

The engine rotation adjusts itself automatically in accordance with the coolant temperature alteration.

After engine start up, the vehicle can be put immediately into operation.

Note:

- a. The engine should be running at low middle speed for 3-5 minutes on every day's first starting before the driving.
- b. Never race the engine without warming up. During cold start, increase engine speed slowly and do not make engine run at maximum speed until water temperature of engine reaches to 70°C. At any time, do not make engine run at high speed under no load.
- c. Never make engine run at idle speed for more than 10 minutes.
- d. The oil pressure should be displayed on the dashboard in 15 seconds after the engine is started, otherwise, stop engine to check..
- e. If parking brake indicator lights, indicating that parking brake has not be released.

Attention!

If on starting up the engine, the engine oil pressure indicator continues indicating low pressure, this means that the engine running order is in danger. Immediately shut down engine, find and correct the failure.

Engine shut down

Loosen accelerator pedal.

Place the gear box lever in neutral position and apply the parking brake.

Turn the ignition key to the off position, without accelerating.

Note: After engine runs at heavy loading, temperature of cooling water is higher than 90°C, so do not stop engine at once. The stalling should be made only after the engine has been running for a period of time and the water temperature lowed to the normal range. The parking brake is achieved by setting the hand brake handle on the control position after the stalling. The shift should be switched to the neutral position and power supply shut down. Please make necessary inspection of engine and then troubleshoot.

Cautions

Cautions during the winter operation

- ① Please add long life coolant to cooling system.
- ② After parking, please exhaust water in air tank in time.
- ③ Before winter comes, please check level of battery electrolyte, specific gravity and voltage.

Water used in the radiator must be soften.

Never make engine start without preheating or run with trouble. In the cold climate, do not start engine until preheat it with hot water or vapor to more than 30-40°C.

During driving downhill, do not place gearshift lever in neutral position to slip. Please apply exhaust brake or retarder.

Do not start vehicle until parking brake has been released

Engine start up and shut down in the engine compartment

Park the vehicle and activate the parking brake.
 Put the gear box lever or the automatic transmission selector in neutral (dead point).
 If the transmission is in gear position, the start up with in the engine compartment will not work.
 Turn the ignition key to gear position, without activating engine start up.

Engine start up

Press the start up switch (start) and activate the back cover course end switch bar in the engine compartment.
 Loosen the switches immediately the engine begins running.

When the engine is turned on by way of the start switch in engine compartment, and with the engine compartment gate open, the start engine by way of the ignition key is impossible.

Engine shut down:

Press the shut down switch (STOP).

To make the engine turn without starting up:

Press the engine start up and shut down buttons simultaneously.

Note: the final placement of the switches in the engine compartment is the responsibility of the vehicle body manufacturer.

Model 1



Model 2



Model 3



Starting the vehicle

The vehicle could only be started when braking system pressure has reached 5kg/cm^2 above and each instrument and indicator lamp is on the proper condition, and the coolant temperature exceeds 60°C as well as the parking brake has been released after the engine is started. Please make the startup in shift I.

On normal running condition:

- Pointer of oil gauge should be between 0.2 and 0.4Mpa ($2\text{-}4\text{kg/cm}^2$).
- Pointer of water temperature gauge should be between 83°C and 95°C .
- Pointer of barometer should be between 0.55 and 0.8Mpa ($5.5\text{-}8\text{kg/cm}^2$)

After the vehicle starting, gear shifting should be made step by step and timely. The clutch pedal should not be released abruptly to impulse the starting when the vehicle is stuck in the mud or can not start on a spoil road.

The following problems should also be paid attention to during the driving

- ① If abnormal noise or odor occurs, please stop vehicle to check.
- ② Abrupt acceleration or emergency braking should be avoided as might.
- ③ Don't put foot on the clutch pedal during the driving.
- ④ Avoid engine overspeed. When driving long downhill, engine may overspeed easily after gearshift, at this time, pay attention to apply exhaust brake or retarder and service brake to ensure engine run at specified speed.
- ⑤ During driving downhill, never stop engine, otherwise, resulting in low pressure in brake pipeline and power steering gear failure.

During normal running condition, the pointer of water temperature gauge should be under the red sign that indicated the vehicle is on normal condition, if the pointer is on "H" indicate it is abnormal.

Parking the vehicle

The parking brake should be always applied when the vehicle is parked.

Additionally, in some countries, it is determined by law that a vehicle parked on a slope must have at least one of its wheels wedged, to prevent its accidental moving.

In this case, always keep an appropriate wedge available for this purpose aboard the vehicle.

When parking on public highways, obey the legal determinations as far as the use of parking lights or reflecting panels.

Parking brake handle

Pushing forward the brake handle is of driving state.

Pushing backward the brake handle is of parking state.

Always activate the parking brake when the vehicle is parked.

Besides activating the parking brake, when parking on upward or downward slopes, wedge one of the vehicle wheels to avoid the accidental moving of the vehicle.

Application


Attention!

On applying the parking brake, always check the locking of the lever in the total braking position, on the contrary, the lever may return automatically to the brake off position.

Pull back the parking brake valve lever in such a way that the lever is locked in total braking position. The parking brake warning light should light up.

Note:

In emergencies, with the possible failure of the service brake, the parking brake can be used as an emergency brake. In this case, slowly pull the parking brake lever allowing for a progressive braking without abruptly locking the wheels.



General knowledge

King Long recommends that the bus be maintained according to the Maintenance Schedule in this section. Perform maintenance at whichever interval occurs first. At each scheduled maintenance interval, perform all previous maintenance checks they are due for scheduled maintenance.

King-long Bus General Maintenance

Please make periodic inspection and maintenance of bus according to the operation manual to ensure good status. During service, stop bus on a horizontal road and ensure bus steady and engine stopping. Make functional inspection and running test after each service.

Important Notice: If bus often runs under poor conditions (such as poor road surface, high dust concentration, frequent bump etc.), maintenance interval should be shortened. During adding lubricant, before replacing filter or repairing, clean the place around related parts carefully. Please add lubricant with clean containers.

Maintenance of engine and chassis assembly

- For the usage and maintenance of the engine, refer to relevant engine operation and maintenance manual.
- For maintenance of transmission and front-rear axle, please refer to relative users' guide.
- For use and maintenance of other parts of chassis, if without special user's guide or maintenance period, please refer to this manual for maintenance information.

Body maintenance

1. Keep body clean .Timely clean should be made after daily running and don't scrape body with tool in order to avoid paint scratch and damage of roll covering.
2. Sealing strips of doors and windows should be kept integrated. Make timely replacement if damaged.
3. Prohibit washing body paint with hot water, buck, kerosene and other liquid which has damage to oil paint.
4. Check connections between body and frame frequently. If find something abnormal, repair it in time.
5. Frequently check fasteners inside vehicle and tighten them in time.
6. Frequently check conditions of passenger door. If find something abnormal, do adjustment in time.
7. Frequently check conditions of all lamps. If find any damage, replace it in time.

ABS/EBS system maintenance and service:

1. Please cut off ECU control box to avoid the high voltage from outside to make damage to the ECU, when use the outer power supply to charge the battery.
2. When the vehicle need electric welding, cut off the ECU .never use the multimeter to measure the ECU box.
3. Inspect the engine voltage for stabilization periodically.
4. When maintain the brake shoe , do not damage the ring gear and sensor, clean the ring gear and sensor at the same time. after maintenance ,do remember to put the sensor to the limited position along the ring gear direction.
5. Make sure that the power is in off position when remove and install the components, keep the components clean and dry.
6. Never change the fuse capability or connect the fuse in disorder.
7. Change the indicator in time when it doesn't work.
8. Do not brush the ECU with water when cleaning it.

Note: for details about the working theory of ABS and maintenance, please refer to the ABS instruction book which is offered by provider.


Because of different allocation requirements, some of the vehicle model may not be equipped with ABS system, please use correctly according to actual condition of vehicle.

Electrical system maintenance and service:


- (1) When battery is charged by external power supply, disconnect ECU to prevent outer high voltage damage ECU (electric control unit).
- (2) When vehicle needs to weld, disconnect ECU. Don't use multimeter to measure ECU control box.
- (3) Monitor voltage stability of generator regularly.
- (4) Parts dismantling must be carried out after electric has been shut off and should keep parts' cleanness and dry.
- (5) Don't change fuse capacity casually or bestride connect fuse.
- (6) When indicator doesn't work, replace it timely.
- (7) Don't use water to scour ECU when doing ECU cleanness.
- (8) Don't use multimeter to measure ECU.

Tire transposition

The tire may appear certain abrasion after period of running. The tire should be made transposition as the drawing below after every 8000 km to 10000 km running for proper use and prolonged tire life. Four-wheel locating condition should be checked, dynamic balance and tire transposition be made at once if there shows early and irregular abrasion of the tire.



Tire transposition diagram (two axles)



Tire transposition diagram(three axles)

Adjustment of the brake pedal free play

Loosen locknut of brake pedal push rod and adjust adjusting nut, and then measure the vertical distance from pedal free position to the position where pressing resistance increases apparently when depressing pedal. The value should be between 8mm and 12mm. After adjustment, lock the locknut.

Bus cleaning

- Don't pollute the environment when washing vehicle at washing shop.
- Be careful to use the high strength dissolve fluid.
- Don't damage paint layer.
- Do not directly inject the water into radiator grill on right (left) back of the bus to prevent the water from entering engine through the air filter.
- Don't pour water onto electrical equipment in order not to damage it.


Cleaning the air filter

Hint: Please replace filter element under such conditions: it has been washed 5 times; filter element has been damaged; filter element is clogged excessively; after changing the engine oil. When air filter indicator on combination instrument lights, clean the air filter or replace the element.

Dirty air filter would lead to deficient power and engine worn. In order to assure the life and normal operation of engine, please perform periodic maintenance on air filter.


Check and maintain air filter every 2000km. Under some conditions, such as heavy dust and etc., interval time should be shortened.

The engine must be stalled during the air intake system maintaining and the engine should not be started after withdrawing the filter.



- (1) Remove butterfly nut on cover cap and take down cover cap and then take out filter element
- (2) Clean interior of the cover and the housing with a clean and dry napery. when cleaning the filter cartridge. prevent the water from entering the air filter.
- (3) Exclude dust in unloading valve.
- (4) The filter element may be cleaned by hand or by tapping the end surface with a wood bar or blown by compressed air. Also wash with lotion. But take care not to break element.

Blow with compressed air: blow the filter element from inside to the outside with the dry compressed air of the pressure not exceeding 5bar until there has no dust blown out.



Caution: Outside surface of the filter cartridge should be cleaned with cloth instead of blown with compressed air.

Wet washing: Put filter element in lukewarm containing general cleaning agent and swing it and then clean with fresh water and dry it after dehydration.

Hint: Before wet washing, blow filter element clean.

Caution: Vapor spray gun, solution, gasoline or equivalent should not be used during the cleaning.

— Before reinstalling air filter element, check element from inside to outside with check lamp for damage;

— Check sealing ring for damage or cracks.

Caution: Do not start the engine without mounting the air filter.

Clean outside of the radiator

Keep outside of radiator clean. Compressed air current can eliminate all the dirt blocking air flow.

For vehicle equipped with intercooler, please keep air radiator fin clean. If there is hard dirt in radiator fin, blow fan side and then the other side with compressed vapor current. In order to avoid damage to air radiator fin or water radiator fin, ensure spray of air, water or vapor perpendicular to radiator surface. It should be sent to the king-long special maintenance station to make decontamination and final disposal if there has much dirt in the water radiator and the air radiator.

1. Clean water radiator fin and air radiator fin termly and eliminate dirt blocking air flow, which is important for ensuring the engine cooling.
2. For zone with many winged insect, please clean radiator fin frequently.
3. If users do not operate according to requirement, resulting in poor engine cooling and grave damage to components.
4. If don't comply with this requirement, it may cause poor engine cooling and bad damage to components.
5. Anti-freeze and antirust solution (mixture of glycol and water) should be added to cooling system perennially to avoid sediment, frost, oxidation and increase boiling point.

Note: When adding coolant, please choose the same model as much as possible in case of sediment. If coolant is degenerative, replace it entirely and immediately.

- 6 . Never use water to replace coolant for a long period.

After long running of engine, scale will come into being in cooling system. It should be eliminated in time. Methods as follows: mix 700-800g caustic soda with 150g kerosene and then inject the mixed liquid into cooling water and make engine run at middle speed for 5-10 minutes. 10-12 hours later, make engine run again for 10-15 minutes and then drain aqueous solution and clean cooling system with clean water.

Charging-up the coolant

Anti-freeze and antirust solution (mixture of glycol and water) should be added to cooling system perennially to avoid sediment, frost, oxidation and increase in boiling point.

NOTE: When adding coolant, please choose the same brand as much as possible in case of sediment. If coolant is degenerative, replace entirely.

Coolant specification as shown below: the users should choose proper brand according to requirement:

Specs °C	Max. boiling point °C	Content of glycol	Pure water	Additive
-45 °C	108.00 °C	58%	32%	10%
-40 °C	107.50 °C	54%	36%	10%
-35 °C	107.00 °C	50%	40%	10%
-30 °C	106.50 °C	46%	44%	10%
-25 °C	106.00 °C	42%	48%	10%
-20 °C	105.50 °C	38%	52%	10%
-15 °C	105.00 °C	34%	56%	10%
-10 °C	104.50 °C	30%	60%	10%

Fuel recommendation

1. Diesel fuel (only apply to diesel vehicle) : only diesel of which cetane value is not less than 45 according to GB252 standard can be used. Sulfur content should not be more than 0.2%.
2. No. 0 light diesel fuel: Suitable for the zone where venture rate is 10% and minimum temperature is higher than 4°C.
3. No.-10 light diesel fuel: Suitable for the zone where venture rate is 10 percent and minimum temperature is more than -5°C.
4. No.-20 light diesel fuel: Suitable for the zone where venture rate is 10 percent and minimum temperature is more than -14°C.
5. No.-35 light diesel fuel: Suitable for the zone where venture rate is 10 percent and minimum temperature is more than -29°C.
6. Natural gas (only apply to Natural Gas Vehicle):use natural gas of which methane value is low to 65.

Oil quality and specification recommendation


Engine oil

- Prefer using the engine oil whose quality is equivalent to or higher than level CF-4 or CH-4 of American Petroleum Institute API, or refer to the engine specification.
- Part of engine oil used for lubricating the piston will be burnt out (consumed) during the engine running. Engine oil must be replaced in certain period because of high temperature effect and the oil combustion product interfusing in the oil, especially the chemical additive in the oil will cause "abrasion" of the oil. This kind of abrasion depends on working condition of engine, quality of fuel and engine oil; therefore there has different oil changing interval. (Recommended oil changing interval is 12000km.)

Engine oil viscosity


- Since oil viscosity fluctuated with temperature, so the ambient temperature of engine working area is very important to select viscosity grade (as shown in the figure). When temperature exceed lower limit, it may decrease cold start capacity of the engine but will not make any damage to the engine.
- Higher sticky engine oil may cause the engine difficult to start, so the ambient temperature of the engine starting is the main reference for selecting viscosity of the winter engine oil. Selecting multifunctional engine oil may avoid oil changing caused by temperature fluctuation.

HINT: Never add any additive to above engine oil and different kinds of oil should be avoided using at the same time (oil mixture must be the same grade oil and it is recommended to replace in time).



Gear oil:

Apply gear oil in accord with SAE90 API GL-5 grade. Recommended gear oil viscosity grade is related to ambient temperature, as shown in figure.



Power steering hydraulic oil:

Fulfill standard: please apply DEXRON-II D or DEXRON-III hydraulic fluid to steering gear;

Final drive lubricant:

Meet the using condition of GL-5(SAE90) grade heavy duty hyperboloid gear oil defined by API and the ambient temperature requirement.

Clutch oil:

➤ It is compound brake fluid (DOT3) and must fulfill the standard GB10830-98JG3, GB12981 91H2Y3. It should be paid attention not to mix brake fluid with different types, otherwise it will affect the using effect. The original brake fluid should be cleaned out before replacing the compound brake fluid.

Chassis grease:

- Grease added in each part should use 2# lithium base lubricant (suitable for temperature within the range of -30~ +120°C).
- Vehicle with centralized lubrication should use 0# lithium base lubricant.

Water tank coolant:

- Long life anti-freezing and antirust fluid should be added to water tank. The coolant could be general used both in winter and summer without adding and draining water in winter and it can prevent forming scale and corroding cooling system. Freezing point of the coolant should be noticed to 5°C lower than the lowest environment temperature. Different type of coolant should not be mixed using.

- Replacing period of the coolant is 2 years.
For specification of the coolant please see the section "filling up coolant" in the chapter "maintenance and service".

Breaking-in of New Vehicle

Engine of new vehicle should be sure not to operate at the maximum power output during the breaking-in period to keep best performance and superior efficiency as well as guarantee durable service life. Please drive cautiously and pay more attention to abnormal phenomenon occurred during breaking-in period. Given break-in mileage of the new vehicle is 5,000 km. please run at speed under 100 km/h in breaking-in period.

Preparation before breaking-in of the new vehicle

1. Wash the vehicle and check connection and tight situation of each place.
2. Check coolant storage in radiator and check each place of cooling system for leakage.
3. Check oil level of engine, clutch control system, transmission, drive axle, steering gear and clutch oil storage tank. If deficient, add and then check each place for leakage.
4. Check and see if braking system works properly and leakage phenomenon exists at connections of all valves and pipelines.
5. Check and see if phenomenon of loosening or clogging exists at each place of steering system.
6. Check and see if electric equipments, lamps and the instruments work properly and check battery electrolyte level.
7. Check whether tire pressure has meet requirement.
8. Check and see if each transmission gear can engage properly.

Maintenance during breaking-in period

1. Running on smooth and good road surface.
2. Drive properly and engage the clutch smoothly. Gear shifting smoothly and impact is not allowed. Neutral gear sliding is forbidden while engine stop. Emergency brake should occur as few as possible.
3. Speed limitation during breaking-in period: first gear \leq 10km/h, second gear \leq 20km/h, third gear \leq 30km/h, fourth gear \leq 50km/h, fifth gear \leq 60km/h, overspeed gear using can not be permitted during breaking-in period .
4. Load limit: No load within 250km and never overload after 250km.
5. Often pay attention to the temperature of transmission, drive axle, wheel hub and brake drum. If overheating severely, find out causes and eliminate in time .
6. Pay more attention to keep the pressure of engine oil and the temperature of engine coolant within the normal range.

Maintenance after breaking-in period

1. Tighten cylinder head and bolts (inc suspension). Tighten torque please refer to corresponding instruction. Tighten torques please refer to corresponding instructions.
2. Check valve clearance.
3. Check lubricant level of final drive and clean ventilation plug.
4. Replace engine oil、 axle oil and oil filter element.
5. Replace hydraulic oil and oil tank filter of power steering hydraulic system.

6. Check connection of transmission control mechanism for looseness.
7. Check connections of steering gear for looseness and damage.
8. Tighten bolts and nuts of front and rear suspension (carry out when full load)
9. Check connections of chassis and driving system according to specified torques. Tighten torques please refer to corresponding instructions.
10. Check hydraulic system components of steering mechanism for fixing and tightness
11. Lubricate and maintain vehicle according to maintain items at 5,000km.
12. Check complete vehicle for oil, water and air leakage.

Daily Maintenance Operation

System	Item	Operation	Technical requirement
Engine	Air cleaner	Check	No leakage, damage, and crack.
			Clips without looseness.
	Fuel-water separator	Drain	Release the water and fouling
	Cooling fan	Inspect	Do not pull or lever the cooling fan for starting the engine.
			No crack, looseness, bend or damage.
	air inlet/ outlet piping	Maintenance check	Pipes without wear and damage, clips without looseness prevent the air leakage.
	Coolant level	Check	Do not remove the water tank cover, unless the temperature is less than 50°C, otherwise, it's dangerous for operator
			Do not add the cold coolant into the hot engine, unless the engine temperature is less than 50°C
	Engine oil level	Check / correct	Do not start engine when oil level less than “L” or more than “H”.
Vehicle parking level, check the oil after engine stops for 5 minutes			
Drive belt	Check / correct	No across crack, wear or material break off	
Crankcase breather tube	Check	Check the breather tube in cold winter, cleanup the ice blocking.	
Engine and Accessories	Check	No damage and crack	
Clutch	Clutch pedal free stroke	Check / adjust	Clutch release bearing clearance
			Free stroke: 30 ~ 40 mm
	Clutch system	Check	Check if clutch separated completely, connection stable and not skidding
	Clutch brake fluid level	Check / add	Compound brake fluid
Brake chamber stroke	Check / adjust		
Air suspension	Vehicle body	Check	Observe the vehicle body whether tilt or not, the air spring (or piping) of one side is leaky if this side is lower.
	The air springs	Check	If hear the sound of leaking obviously, we can deal with the problem after confirming the specific leaky location
Training	1. Correct operation: no neutral speed skidding; no idle speed running of engine for a long time		
	2. Correct maintenance: replace oil, oil filter element, diesel filter element, transmission, axle, angle transmission system periodically, clean and replace air filter element periodically		

Periodical maintenance and operation items and regulations

Periodical maintenance of each class: do maintenance during each interval or certain miles .

Special instruction: if assembly instruction requires different oil replace period, please follow the instruction's requirement on maintenance period and operation. If else please refer to this manual for maintenance requirement.

Maintenance operation and regulation every 5000km or 1 month depend on whichever occurs first.

Maintenance operation and regulation every 5000km

System	Item	Operation	Technical requirement
Steering system	Working condition	Check	Steering wheel max free rotation at middle 10 degrees
	redirector auxiliary oil and filter element	Check	Below 10℃ use DEXRON-II; above 10℃ use C-3/10W
	Fix bolts of each place	Fasten	Each fastening bolts not loosening, steering arm not loosening, steering wheel swift,
	Ball head	Lubricate	Each turning ball head not loosening, no clogging, clearance normal
	ZF series		Maintenance Free
	GX85, GX 100, ZJ 100C	check	For first 5000km only, N32 which manufactured by Shanghai oil refining factory or ATF or related products which produced.
	IPS40-SB8575D series	check	For first 5000km only, Environment temperature >10℃, adopt CD level 15W/40 oil; Environment temperature <10℃, adopt No.8 hydraulic drive fluid.
Transmission (QJ series mechanism transmission)	Transmission fix bolt	Fasten	
	Transmission and Accessories	Check	No leakage, operation organization effective, no abnormal sound, wrong gear engagement.
	Lubricant oil	Change	The lubricant ZF-Ecofluid M 02E is compulsory for initial fillings of transmissions as well as fillings during transmission break-in (only first 7500km)

System	Item	Operation	Technical requirement
Front axle (DF & FS series)	Brake clearance	Check & adjust	
Rear axle (DF & FS series)	Brake clearance	Check & adjust	
Air suspension	Fasteners	Check/tighten	Check and tighten the bolts, rods, height control valves, air springs, shock absorbers, anti-roll bars.
	The top covers of air springs, height control valves and the joints of the air course	Check	Listening and wiping the liquid soap. If find any place is leaky, please either tighten the joints or change the seal tape and clean the accumulated water, oil in the piping and the dirt in the joints
Air suspension	The exterior surface of air springs	Check	Find out the places which are abraded, distended, bumped or cut
	The air spring	Change	The surface of the air spring is damaged and appears the cord fabric
	The air spring	Adjust/check	If air spring interfere and knock with the components around it, please adjust it in time.
	The air spring surface	Check/clean	Clean the lubricant grease on the surface, the dirt on the piston, the abnormal things placed between the piston and air spring.
	The air spring	Check	If there is leakage in the joints of the air springs and the top cover, the air springs should be taken apart, then check whether the edges of the air springs and the top cover or the tapered sealing zone are distorted. Change it if it is distorted.
	The bumper	Check	It's damage maybe the root damage of the tapered sealing zone
Air suspension shock absorber	The height control valve	Check	If a height control valve controls two air springs and one air springs is leaky, the other air springs has not air too.
	Shock absorber	Check	The external damage, the welding damage and the sealing damage result to the leakage of the shock absorber.
	The rod	Check	Check the rubber of the rod ball head and the rivet of the sleeve pipe and the ball head. Check the clamp and the tighten bolts if the it is the adjustable rod
	The rubber liner	Check	Check the ball joints of the anti-roll bar and the rubber liner bushing of the boom

System	Item	Operation	Technical requirement
Brake System	The brake pedal free stroke	Check & adjust	10 - 15mm
	The braking condition	Check	Shoe drum clearance: 0.30mm ~ 0.50mm, in complete braking, pedal stroke not surpass 1/2 of the whole stroke, check dry tin condition
	The brake pressure	Check	Check whole vehicle brake pressure as required or not. Above 0.6MPa
	The brake nuts	Inspect	Inspect fastening of rear brake board's nut 7.7 - 9 (m): 150-180 Nm, 9m above: front;160-205 Nm, rear:196-245 Nm
	The pipe and joint sealing	Check	Check brake pipe and joint sealing , No leakage
Chassis	Fastening body and chassis connective bolts, nuts	Check	
	The whole vehicle body butter nozzle	Lubricate	Grease nozzle complete and effective, lubrication good
Electrical equipment	The whole vehicle light and instrument	Check	
	The battery fluid surface	Check	Add distilled water,
	The wire joint firmness, no rust	Check	No rust
	Air-con radiator filtration net	Clean	

**Maintenance operation and regulation every 10000km or 3 months depend on whichever occurs first.
Every 10000km include every 5000km maintenance operation**

System	Item	Operation	Technical requirement
Engine	Oil	Replace	Check oil surface within required range
			Check engine and oil seal without apparent leakage
			Replace oil when engine water temperature is 60°C, for removing the impurity
			Oil level more than CF
	Oil filter	Replace	Before installation add 1/2—3/4 to filter
	Air filter	Check	Clean air filter element
	Air inlet/ outlet system	Check	No air leakage, no damage, each clip fastening good
	Cooling system and Intercooler	Check	No leakage, each clip without damage or loosen
			Water tank without leakage, damage, fouling
	Coolant filter	Replace	Before re-install the coolant filter, daubs the 15W-40 lubricate oil on the interface of the sealing ring.
	Fuel pump installation	Check	No leakage
Air compressor	Check	No air, oil, coolant leakage, lock nut and bolt no loosen or damage	
		No carbon deposit	
Brake system	Check	No leakage	
Propeller shaft	fastening bolt	Check and fasten	Propeller shaft flange fastening bolts not loosening
	universal joint	Check and fasten	Universal joint each bearing no loosening or damage
Front axle (DF series)	Brake bottom board	Check	No loosening
	Hub bear	Check	No loosening
	Brake plate	Check / change	Change the brake plate when plate abrasion more than limit pit.
Rear axle (DF series)	Brake bottom board	Check	No loosening
	Hub bear	Check	No loosening
	Brake plate	Check / change	Change the brake plate when plate abrasion more than limit pit.
The leaf Suspension	Leaf spring	Check	Each fastening bolt not loosening, leaf spring no broken piece, no apparent change of elasticity
Brake system	Rear braking system	Check	Check brake friction piece thickness within required range by check port, visual check brake adjust arm working condition, running and stop brake good, each brake pipeline and air line no leakage

**Maintenance operation and regulation every 20000km or 5 months depend on whichever occurs first.
Every 20000km include every 10000km maintenance operation**

System	Item	Operation	Technical requirement
Engine	Fuel filter	Replace	Replace fuel filter element accordingly
	Steering hydraulic oil	Replace	Steering auxiliary oil surface within required range
	Coolant system – anti-freezing	Check	Check the density of anti-freezing
Propeller shaft	Dust-proof cover	Check	Dust-proof cover without crack, damage, clip reliable, bracket no loosening
	Universal joint condition	Check	Universal joint without loosening, no block abnormal sound
	Propeller shaft bracket	Check	Propeller shaft bracket no loosening, screw torque 120 ~ 140Nm
	Middle bearing clearance	Check	Middle bearing clearance no more than 3mm
	Lubricate	Lubricate	Lubricate each butter nozzle with 2# lithium lubricant grease
Steering system	GX85, GX 100, ZJ 100C	Change oil and filter core of oil tank	N32 which manufactured by Shanghai oil refining factory or ATF or related product which produced.
	IPS40-SB8575D series	Change oil and filter core of oil tank	Environment temperature >10 °C , adopt CI level 15W/40 oil; Environment temperature <10 °C , adopt No. hydraulic drive fluid
Front axle	Toe-in of front wheel	Check & adjust	Radial-ply tire: 0 ~ +2mm
Rear axle (DF & FS series)	Final drive	Filling-up	From injection hole into final drive filling Parathion-type 90 heavy-duty gear oil (GL-5) to the face. (for first 1500km, than change for every 24,000km)
The leaf suspension		Check and fasten, weld accordingly	Not loosening, crack, fracture, misplacement, screw U bolt, front 196 ~ 294Nm, rear 343 ~ 392Nm
The air suspension	The liner bushing of the rod assembly	Change	The liner bushing is relative sliding with the ball head
		Change	The liner bushing is knocked to bend and the tighten bolts of the adjustable rod are becoming invalid which result to the threads of the ball head and the steel pipe damaged.
	The rubber ball joints	Change	The crack on the surface of the rubber is very serious. The depth of the crack is up to 2mm and the length of it is up to 8mm

System	Item	Operation	Technical requirement
The air suspension	The rubber ball joints	Change	There are gaps on the surface of the rubber
			The surface of the rubber become adhesive, brittle and the rubber drop off seriously
			The connection of the metal and the rubber is damaged. The partial depth is up to 6mm
			The rubber ball joint rotates in the inner hole of the ball head and will
	The height control valve.	Check adjust	Check the equilibrium position of the adjustment bar of the height control valve.
	The rubber of the link rod	Change	Change it if the rubber of link rod becomes ageing, brittle, adhesive and lose its elasticity
	The connecting members of the shock absorber	Check change	Check the connecting members of the shock absorber if they are damaged please adjust or change them.
the rubber	Check change	If the rubber is crack, brittle, adhesive and loses its elasticity please adjust or change them.	
The height	Check adjust	Charge the air springs and adjust to the design height, then check the wheel base, the height of the vehicle body and the two side wheels' locations which are relative to the frame. If it is necessary please adjust the height of the air springs and the length of the rod in order to arrive to the design request	
Brake system	Brake pedal free stroke	Check	Break pedal free stroke 12 ~ 15mm
	Brake valve and pipe joint	Check and fasten	Break valve and pipe joint connection reliable and without air leakage
	ABS system	Check	ABS working properly
	Auxiliary brake, stop brake free stroke	Check	Effective, 20% dual direction stopping at slop reliable
	Retarder	Check	Retarder working properly
	Engine exhaust brake	Check	Exhaust brake working properly
Body, frame	door lock function	Check	Lock function good Sealing good
	cabin door sustain pole or air spring	Check	Cabin door lock function good, sustain pole or air spring effective
	inside and outside mirror	Check	Complete, no crack, effective, mirror clean, installation firm and reliable

System	Item	Operation	Technical requirement
Body, frame	front rear wind shield and side window glass	Check , clean	Clean, no crack, sealing good
	body with paint	Check	Body paint no crack or peeling, re-paint color the same as original
	pattern, character, company mark	Check	Pattern, character, company mark clear, complete
	Body and frame	Check	Function reliable, working properly, no distortion, crack, fracture, welding split, connective bolts and rivet fix firm and reliable
Inside establishment	Driver seat	Check	Fix firm, front rear up down lock function reliable Installation firm, backrest angle adjust lock function reliable
	Safety set	Check	Safety belt function good, connection reliable, fire extinguisher, urgency hammer complete and effective
	seat cover, carpet, curtain and armrest	Check	Clean, complete and firm
Compressor, air reservoir, safety valve	Compressor, air reservoir, safety valve	Clean, screw	Clean, connection reliable, no air leakage, safety valve normal, pressure at 8Mpa, check air reservoir, if with seeper, replace air drier filter element
Electrical equipment	Front lamp, horn, meters and signal	Check	set complete and effective
	Wiper generator	Check	Effective
	Wiper connection rod	Check, adjust	Reliable
	Whole vehicle wiring	Check, adjust	complete, reliable, insulation good
Air-conditioner	Air-con passage and read lamp control panel	Check	Air-con passage installation reliable, functional and effective
	Air vent set	Check	Installation firm , working properly
	Air-con strap tension and surface condition	Check	Tension proper, strap without crack, scuffing or distortion
	Magnetic clutch, fill lubricant	Check	Work properly, lubricant: 2# lithium grease
	Air-con pipe	Check	No leakage or interference
	Condenser, evaporator	Check	Clean, no dirt
	Coolant and fuel qty	Check	Up to requirement, fill if necessary
	Control switch	Check	Installation firm, operation normal and reliable
Heating system	Fuel, water heat pipelines	Check	No crack, oil, air or water leakage, joint not loosening, oil and water pipelines smooth
	Heating device	Check	Pipeline connection reliable, operation good

**Maintenance operation and regulation every 40000km or 8 months depend on whichever occurs first.
Every 40000km include every 20000km maintenance operation**

System	Item	Operation	Technical requirement
Engine	Drive belt, Cooling fan belt tension	Check/adjust	Check each belt without loosening or damage
	Cooling fan bearing and bolt	Check/adjust	No damage, fouling, loosening
	Belt tension pulley bearing	Check/adjust	No damage, fouling, loosening
	Cylinder cover bolt	Check/adjust	No damage, loosening
	Air dryer	Replace	Replace air dryer
Suspension	Leaf spring bushing	Check	Clearance between leaf spring bush and pin normal, no abnormal abrasion, bush not crack, lubrication normal

**Maintenance operation and regulation every 80000km or 12 months depend on whichever occurs first.
Every 80000km include every 40000km maintenance operation**

System	Item	Operation	Technical requirement
Engine	Thermostats	Replace	
	Fuel roughing filter	Replace	
	Cooling system	Release/ clean/ add	
	Radiator	Check	Radiator without leakage, damage, fouling. Hose without damage, clips without loosen or damage.
	Engine suspending	Check/fasten	Connection reliable, firm, soft mat no distortion layer or crack
	Overhead set- valves and injectors	Measure	Valve clearance within required range
Clutch	Clutch brake fluid level	Charge	Compound brake fluid
The leaf suspension	leaf spring bushing	Check	Clearance between leaf spring bushing and pin normal, no abnormal abrasion, bushing without crack, lubrication normal

Maintenance operation and regulation more than 80000km or corresponding time interval.

As for Cummins engine, ZF Series products, Allison and VOITH products, they will apply for their own special oil or grease change interval, please refer to the covering maintenance illustration from “King Long Bus Maintenance & Service Guide (2014)”

Maintenance period chart																		
1、1st line is the item of break-in of new vehicle (prescript items completed after driving 5000KM or the day of registration vehicle) 2、Other items are compulsion maintenance program (the circulation is 80000KM/12 months) 3、For engine, axle, transmission please refer to producer's maintenance manual, if without special maintenance period, please refer to this manual for maintenance information. 4、“R” meaning: Replacement ; “I” meaning: Inspection & adjusting; “C” meaning: Cleaning																		
Maintenance item	Maintenance period																	
	*1000km	5	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
	Month	1		3		5		7		8		9		10		11		12
Engine																		
Engine oil	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I
Oil filter	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I
Fuel filter element	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I	R	I
Air filter element	C	C	C	C	C	C	R	C	C	C	C	C	R	C	C	C	C	
Check& adjust belt	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Check & adjust engine idle speed	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Fixing every bolt and connection on engine	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Checking seal of pipe & connector	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Coolant	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	R
Fuel system	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Oil & water separator	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Lubricating oil in gearbox of fan angle steering gear	R		I		R		I		R		I		R		I		R	
Air compressor, air reservoir & pipe	I&C				I&C				I&C				I&C				I&C	
Radiator & expand water tank	I				I				I				I				I	
Fuel tank & oil pipe	I				I				I				I				I	
Fuel pump	I				I				I				I				I	
Water & oil separator core	I				R				R				R				R	
Handle fuel pump	C				C				C				C				C	
Water pump	I				I				I				I				I	
Intake & exhaust manifold, muffle, exhaust pipe	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Turbocharger	I&C				I&C				I&C				I&C				I&C	
Intercooler	I&C				I&C				I&C				I&C				I&C	
Engine suspension device	I				I				I				I				I	
Valve clearance									I									I
Thermostat									I									I

Maintenance period chart																		
1、 1st line is the item of break-in of new vehicle (prescript items completed after driving 5000KM or the day of registration vehicle) 2、 Other items are compulsion maintenance program (the circulation is 80000KM/12 months) 3、 For engine、 axle、 transmission please refer to producer’s maintenance manual, if without special maintenance period, please refer to this manual for maintenance information. 4、 “R” meaning: Replacement ; “I” meaning: Inspection & adjusting; “C” meaning: Cleaning																		
Maintenance item	Maintenance period																	
	*1000km	5	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
	Month	1		3		5		7		8		9		10		11		12
Clutch																		
Release or meshing if not smoothly	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Oil pipe system	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Clutch plate abrasion	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Free stroke of clutch pedal	I		I		I		I		I		I		I		I		I	
Clutch oil	I		I		I		I		I		I		I		I		I	R
Clutch cylinder & stroke	I		I		I		I		I		I		I		I		I	I
Transmission																		
Transmission if not leaking oil	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Selector mechanism	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Lubricant oil	R		I		I		I		R		I		I		I		I	R
Vent hole	C	I	I	I	C	I	I	I	C	I	I	I	C	I	I	I	C	C
Propeller shaft																		
Drive shaft connecting parts	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Add lubricating oil in drive shaft	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Universal joint cross & bearing	I		I		I		I		I		I		I		I		I	
Fixing the bolt	I		I		I		I		I		I		I		I		I	
Middle bearing bracket & clearance	I				I				I				I				I	
Brake system																		
Brake pedal free stroke adjustment	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Driving brake , parking brake	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake pipe & connector seal	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Air dryer	I	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I	R
Brake air pressure	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
ABS system checking	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake board fixing	I		I		I		I		I		I		I		I		I	
Retarder	C		C		C		C		C		C		C		C		C	

Maintenance period chart																		
1、 1st line is the item of break-in of new vehicle (prescript items completed after driving 5000KM or the day of registration vehicle) 2、 Other items are compulsion maintenance program (the circulation is 80000KM/12 months) 3、 For engine、 axle、 transmission please refer to producer’s maintenance manual, if without special maintenance period, please refer to this manual for maintenance information. 4、 “R” meaning: Replacement ; “I” meaning: Inspection & adjusting; “C” meaning: Cleaning																		
Maintenance item	Maintenance period																	
	*1000km	5	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
	Month	1		3		5		7		8		9		10		11		12
Brake system																		
Brake drum & wearing plate abrasion	I		I		I		I		I		I		I		I		I	
Brake shoe plate clearance	I				I				I				I					I
FR & RR brake checking	I				I				I				I					I
Engine exhaust brake	I				I				I				I					I
ABS unit checking	I								I									I
Brake valve & other valves	I								I									I
Axle & Tire																		
Tire& steel ring	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Checking & fixing RR axle housing & differential housing , RR cover half shaft bolt nut	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Lubricant steering main pin & brake adjusting arm & cam shaft	I		I		I		I		I		I		I		I		I	
Fixing wheel nut	I		I		I		I		I		I		I		I		I	
Tire transposition			I						I									I
Four-wheel maintenance , clean bearing	I				I				I				I					I
Checking & fixing front axle bolts ,nuts, bearings	I				I				I				I					I
Checking & fixing rear axle bolts, nuts, bearings	I				I				I				I					I
Clearance final drive vent hole	C				C				C				C					C
Rear axle gear oil	R				I				R				I					R
Front wheel alignment	I								I									I
Tires air pressure	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Wheel rim, flange, spoke	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Suspension system																		
Thrust pole , connecting pole installation	I		I		I		I		I		I		I		I		I	
Air bag height, seal, integrity	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Suspension system fixing piece	I				I				I				I					I

Maintenance period chart																		
1、 1st line is the item of break-in of new vehicle (prescript items completed after driving 5000KM or the day of registration vehicle) 2、 Other items are compulsion maintenance program (the circulation is 80000KM/12 months) 3、 For engine、 axle、 transmission please refer to producer’s maintenance manual, if without special maintenance period, please refer to this manual for maintenance information. 4、 “R” meaning: Replacement ; “I” meaning: Inspection & adjusting; “C” meaning: Cleaning																		
Maintenance item	Maintenance period																	
	*1000km	5	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
	Month	1		3		5		7		8		9		10		11		12
Suspension system																		
Suspension system lubricate oil	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Absorber working condition	I									I								I
Steel plate suspension bush	I									I								I
Left & right steel plate suspension flexibility	I									I								I
Fixing suspension U type bolt	I		I			I			I			I		I			I	I
Valves function	I									I								I
Bracket & lifting lug installation & wearing state	I									I								I
Steering system																		
Checking steering system working condition, oil leakage	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Steering wheel free stroke & working condition	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Checking power steering hydraulic pressure system	I		I			I			I			I		I			I	I
Steering booster oil & filter core	R		I			I			I		R		I		I		I	R
Fixing bolts	I		I			I			I			I		I			I	I
Lubricating steering ball	I		I			I			I			I		I			I	I
Oil pump working condition	I									I								I
Steering angle checking & adjusting	I									I								I
Checking the crack of steering framework, steering knuckle & knuckle arm, vertical arm & axle										I								I
Main pin clearance										I								I
drive steering hydraulic oil	I	I	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I
Toe-in of front wheel	I					I				I				I				I

Maintenance period chart																		
1、 1st line is the item of break-in of new vehicle (prescript items completed after driving 5000KM or the day of registration vehicle) 2、 Other items are compulsion maintenance program (the circulation is 80000KM/12 months) 3、 For engine、 axle、 transmission please refer to producer’s maintenance manual, if without special maintenance period, please refer to this manual for maintenance information. 4、 “R” meaning: Replacement ; “I” meaning: Inspection & adjusting; “C” meaning: Cleaning																		
Maintenance item	Maintenance period																	
	*1000km	5	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80
	Month	1		3		5		7		8		9		10		11		12
Electrical system																		
All lights	I		I		I		I		I		I		I		I		I	
Battery electrolyte surface , connector	I		I		I		I		I		I		I		I		I	
Wire box installation	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
All wires , circuitry, connectors	I		I		I		I		I		I		I		I		I	
A/C system & pre-heater system																		
Air conditioner system refrigeration working condition	I		I		I		I		I		I		I		I		I	
A/C compressor belt rate of tension	I				I					I				I				I
A/C system pressure, compressor freeze oil quantity	I				I					I				I				I
Autonomous water heat system-fuel supply system	I				I					I				I				I
Autonomous water heat system-water supply system	I				I					I				I				I
Vehicle body, framework																		
Luggage bin door air spring, stay bar	I				I					I				I				I
Engine bin door air spring, stay bar	I				I					I				I				I
Rearview mirror fixing	I				I					I				I				I
Vehicle body, framework checking	I									I								I



The introduce about the lubricate points in King Long bus
At least every 5000 km, all these lubricating points should be lubricated.

There are five lubricate zones in bus

- 1 steering drag rod
- 2 Steering knuckle kingpin, front brake self-adjusting arm in front axle.
- 3 Rear brake self-adjusting arm in rear axle.
- 4 Propeller shaft
- 5 Engine cabin

Part I Lubricate points in the steering drag rod

There are five lubricate points in steering drag link. One is at front end, three at middle, and another at rear end of drag link.



For some buses, maybe there is only one drag link, so there is no points 2/3/4.

Part II Steering knuckle kingpin, front brake self-adjusting arm in front axle

Both left side and right side have four lubricate points. Two are for steering knuckle kingpin lubricating, the other two are for front brake adjusting arm lubricating.




Right side front tire



Left side front tire


Part III Lubricate points in the rear brake self-adjusting arm in rear axle

Both left side and right side of rear axle have two lubricate points. They are lubricating rear brake adjusting arm and brake camshaft.




Part IV Lubricate points in the propeller shaft

There are three lubricate points in the propeller shaft.



Part V Lubricate points in engine cabin

You may find 2 lubricating points when open the engine cabin, one is for A/C bracket, another is for A/C middle idle pulley shaft. There will be not these 2 points if there is no A/C on bus.



Engine common trouble and its elimination (suitable for diesel engine)

Diesel engine can not start

Possible causes	Remedies
1) Too low starting speed	1) Check the starting system and assure the starting speed is not lower than 110rpm.
2) Air exists in the injection system	2) Check the looseness of the joints of the feed line. Unscrew the de-aeration bolt on the fuel cleaner and oil water separator assembly, then press fuel with hand priming pump until the fuel overflows without air bubbles.
3) Fuel pipe clogged	3) Determine the location of the clog and clear it.
4) Fuel filter choked	4) Replace the screw-on filter element of the fuel filter/oil-water separator assembly.
5) Fuel supply pump does not apply fuel or applies fuel irregularly	5) Check for leakage in the fuel inlet pipe Clogging of the fuel supply pump filters and fix or replace.
6) Insufficient fuel injection, without fuel injection or low injection pressure	6) Check the injector atomization situations and replace a new one if it doesn't work.
7) Starting system problems:	7) Check the connection to be correct and reliable.
Incorrect terminals connection or bad contact;	
Insufficient battery charge;	Charge the battery.
Bad contact between the brush and commutator of the starter	Repair or replace the brush and clean the surface of the commutator with soft sand paper and blow off.
8) Insufficient compression pressure;	8) Replace the piston ring and press in the cylinder sleeve if necessary.
Piston ring worn-out	
9) The fuel cut off solenoid valve joint is loose, dirty or corroded smudginess canker	9) Check the valve clearance, valve spring, valve stem, and valve seat. Grind the valve seat if necessary. Tighten and wash or replace.
10) Mounting timing incorrect	10) Check and adjust it.

Diesel engine power deficient

Possible causes	Remedies
1) Intake blocked	1) Check the air cleaner, intake pipe, and clean or replace the air cleaner filter elements.
2) high exhaust back pressure	2) Check the valve timing, adjust it if necessary; Clean the exhaust pipe.
3) Insufficient boost pressure of turbocharged system	3) Check and eliminate the leakage in the pipe and joints.
4) Turbocharger is out of order; Compressor and turbine passages are polluted, clogged or damaged;	4) Dean or replace the compressor casing and turbine housing.
Bearing failure;	Replace it.
Carbon deposit and sludge in the back of turbine and compressor impellers.	Clean it.
5) middle cooler mangle ,leave out	5) Check and replace it.
6) Fuel line blocked or leaky	6) Check the seal of fuel line and fuel filter choking, or replace screw-on filter element.
7) Poor atomization of injector	7) Check the inject pressure, remove carbon, adjust and repair
8) Incorrect distribution phase	8) Check and adjust the distribution timing and valve lash
9) Cylinder gasket leakage	9) Tighten the cylinder head bolts according to the stated torque and order, or replace the cylinder gasket.
10) Bad valve sealing	10) Grind or replace it.
11) Overheat engine or too high coolant temperature	11) Check and repair the radiator, thermostat, and adjust fan belt tension.
12) Piston ring broken	12) replace it
13) Sensor doesn't work	13) Check and replace it.

Abnormal noise during engine operation

Possible causes	Remedies
1) Connecting rod bearing bushing and main bearing bushing are worn-out and clash voice appears in the crankcase.	1) Dismantle and check the bushing and, if necessary, replace it and keep the reasonable clearance as required.
2) The Damper is damaged and invalid.	2) Change components to keep regulated axial clearance
3) The shock absorber is damaged and ineffective	3) Check and see if the joint bolts are in good conditions, and change new ones if necessary.
4) The valve knocks on the piston	4) Check and adjust the valve timing.
5) The driving gear is abraded and get too large gap. There is knocking sound at the timing gear box cover.	5) Check the gear side clearance and change the gear or not according to the abrasion situations.
6) Too big clearance between piston and cylinder and there is knocking sound at the cylinder wall.	6) Change the piston and use the repairing cylinder liner. Keep the proper clearance between piston and cylinder.
7) Puff vibration of supercharger	7) Remove the carbon and waste in the compressor channel and the exhaust channel.
8) The bearing of supercharger is damaged and the rotor knocks on the shell	8) Change the supercharger assembly
9) The valve clearance is too large and there is big noise at the cylinder head.	9) Adjust the valve clearance.

Exhaust with black smoke

Possible causes	Remedies
1) Intake clogged	1) Check and clean the air cleaner and intake passage.
2) Poor fuel quality	2) Use prescribed fuel.
3) Incorrect distribution timing	3) Adjust the distribution timing according to the instruction.
4) Bad atomization of injector	4) Check and repair or replace
5) The injector spray too much fuel	5) Check and adjust it according to the instruction.
6) Check and repair or replace	6) Check and repair leak in the pipe line and joints.
7) Faulty turbocharger	7) Check and replace the assembly.
8) middle cooler damaged and leaked	8) Repair or replace it

Exhaust with white and blue smoke

Possible causes	Remedies
1) Poor quality fuel and too much water in fuel	1) Replace the fuel.
2) Too low coolant temperature	2) Check the working temperature of the thermostat, replace it if necessary.
3) Incorrect distribution	3) Check and adjust it.
4) Too low Pressure	4) Check the working temperature of the thermostat, replace it if necessary.
5) Incorrect installing orientation of piston rings	5) Check and reinstall correctly.
6) Running at low load for long time	6) Operate at proper speed and load
7) Seal ring of turbocharger worn-out	7) Check and replace it.
8) thrust bearing of turbocharger worn-out	8) Check and replace it.
9) Oil return pipe of turbocharger	9) Clean or repair it.

Too low oil pressure

Possible causes	Remedies
1) Diluted or incorrectly selected	1) Select the proper oil.
2) Inner and outer rotors of oil pump worn-out or too large	2) Replace the oil pump.
3) Oil filter choked	3) Replace the whirling type filter element.
4) Failure of oil filter pressure control	4) Repair it.
5) Gear of oil pump damage	5) Replace it.
6) Inlet oil tube of fuel pump crack	6) Repair or replace it.
7) Fixing bolt of oil pump inlet oil tube loose	7) Tighten the bolt to the required torque.
8) Too large bearing bushings clearance.	8) Check and replace it.

Too high oil pressure

Possible causes	Remedies
1) Too low ambient temperature and too high oil viscosity	1) Use the required grade engine oil. Operate at low speed after starting, and then check it when the oil temperature is normal.
2) Over-flow valve clogged	2) Check and clean it

Too high oil temperature and oil consumption

Possible causes	Remedies
1) Leakage in the exterior oil line	1) Check and repair it.
2) Too high diesel engine load	2) Decrease the load.
3) Use improper oil	3) Use the oil as required.
4) Piston ring stuck or seriously worn	4) Check and repair, if necessary, replace it.
5) Too much worn out of Cylinder bore	5) Bore the cylinder and use the oversized piston rings or press in a repair –used cylinder sleeve.
6) Valve guide seriously worn out and failed seal of valve stem	6) Check and replace.

Chassis constant fault and elimination

Propeller shaft

Fault symptom	Possible cause	Eliminating method
<p>Propeller shaft jogging (vehicle vibrates during driving)</p>	<ol style="list-style-type: none"> 1. Propeller shaft sliding yoke assembled incorrectly 2. The propeller shaft is distortion or bending 3. The universal-joint journal or the needle bearing has been worn out or damaged 4. The propeller shaft loose 5. The propeller shaft is imbalance 6. The intermediate supporting bearing is worn out or damaged 7. Bracket of the intermediate supporting bearing is loose or the rubber damping material is aging 	<ol style="list-style-type: none"> 1. Remove and let the sliding yoke and the fixing yoke on the same plane 2. Adjust or replace the propeller shaft 3. Replace the bearing 4. Tighten propeller shaft to specified torque 5. Adjust or replace the propeller shaft 6. Replace the intermediate supporting bearing 7. Make adjustment or replacement
<p>Abnormal sound from the propeller shaft (during the starting and the running)</p>	<ol style="list-style-type: none"> 1. Abrasion or damage of the universal joint 2. Abrasion or damage of the sliding yoke 3. Looseness of the propeller shaft 4. Inadequate lubrication to the needle bearing, the sliding yoke and the intermediate bearing 	<ol style="list-style-type: none"> 1. Replace the universal joint 2. Replace the sliding yoke 3. Tighten it to specified torque 4. Make the lubrication

Transmission

Fault symptom	Possible cause	Eliminating method
<p>Difficult gear shift (Difficult gear engagement)</p>	<ol style="list-style-type: none"> 1. Control mechanism <ol style="list-style-type: none"> 1) Improper height of the control hinge 2) There has clearance between the control hinge connection 3) The control hinge bend 2. Transmission <ol style="list-style-type: none"> 1) Abrasion or damage of the bearing 2) Synchronizer operates abnormally 3) The shaft or the gear is wore or damaged 4) Abnormal slip of the gear shifter shaft 3. Others <ol style="list-style-type: none"> 1) Clutch can not disengage normally 2) The lubrication viscosity is too high 	<ol style="list-style-type: none"> 1) Adjust the control hinge 2) Correct or replace the parts 3) Correct or replace the control hinge 1) Replace the bearing 2) Correct or replace the parts 3) Correct or replace the parts 4) Correct 1) See "Clutch does not disengage smoothly or can not disengage " 2) Use the lubrication of given grade
<p>The transmission gear is off the engaging position</p>	<ol style="list-style-type: none"> Transmission <ol style="list-style-type: none"> 1) Shift fork distorted or worn 2) Abrasion of the lockup ball or the ball on the gear shifter shaft 3) Breakdown or fatigue of the lock spring 4) Excessive clearance of the gear engagement 5) Excessive clearance along the gearing axial direction 6) Abrasion of the sliding bearing slipper or its end surface 7) Abrasion of the main bearing Control mechanism <ol style="list-style-type: none"> 1) The control mechanism is out of work 2) Movement of the shifter lever causes vibration of the vehicle 	<ol style="list-style-type: none"> 1) Check the gear-shifter fork and make adjustment or replacement in case of bending 2) Disassemble and replace the worn-out parts 3) Replace the spring 4) Adjust the gear clearance or replace the gear 5) Measure the axial clearance and replace the thrust washer if necessary 6) Replace the bushing 7) Replace the main bearing 1) Check and correct the control hinge 2) Check damage of the engine rubber suspension and replace the faulted parts

Rear axle

Fault symptom	Possible cause	Eliminating method
Abnormal sound from the rear axle (abnormal sound)	<p>When the vehicle is starting</p> <ol style="list-style-type: none"> 1) Excessive clearance between the differential gear 2) Excessive clearance between the driving and the driven gear 3) Looseness of the connecting flange and the propeller shaft 4) Too small pre-tightening force of the drive gear bearing 5) Looseness of the fixing bolt and nut of the driving gear <p>When the vehicle turning</p> <ol style="list-style-type: none"> 1) There has abrasion or damage to the axle shaft gear, driving gear, spider, thrust shim and the axle shaft bearing and etc 2) Too low oil level 	<ol style="list-style-type: none"> 1) Adjust the clearance 2) Adjust the clearance 3) Tighten it to specified torque 4) Adjust the pre-tightening force 5) Tighten it to specified torque 1) Adjust or replace the faulted parts 2) Fill up the lubrication
Abnormal sound of the rear axle (improper sound)	<p>When the vehicle is running:</p> <ol style="list-style-type: none"> 1) Excessive clearance between the driving and the driven gear 2) Abrasion or damage of the bearing 3) Abrasion or damage of the gear 4) Too low oil level <p>When running with inertia</p> <ol style="list-style-type: none"> 1) Too small clearance between the driving and the driven gear 2) Abrasion or damage of the bearing 3) Incorrect gear engaging position 4) Too low oil level 	<ol style="list-style-type: none"> 1) Adjust the clearance 2) Replace the bearing 3) Make adjustment or replacement 4) Fill up the lubrication 1) Adjust the clearance 2) Replace the bearing 3) Adjust or replace the faulted parts 4) Fill up the lubrication
Leakage of the rear axle lubrication	<ol style="list-style-type: none"> 1. Abrasion, looseness or damage of the oil seal 2. Looseness of the differential lock bolt or damage of the gasket 3. Damage of the differential carrier mating surface <p>Looseness of the oil draining plug or damage of the gasket</p>	<ol style="list-style-type: none"> 1. Replace the oil seal 2. Tighten to specified torque and replace gasket 3. Make trimming and replace the differential housing if necessary 4. Replace the gasket and tighten screw plug to specified torque

Fault symptom	Possible cause	Eliminating method
Leakage of the rear axle lubrication	<ol style="list-style-type: none"> 4. Blocking or damage of the ventilation plug 5. Axle housing cracks 6. Damage or distortion of the coupling flange sealing surface 7. Malfunction of bearing leads to radial run out of coupling flange 8. Axle housing distortion caused by overloading 	<ol style="list-style-type: none"> 5. Clean or replace the ventilation plug 6. Repair or replace the axle housing 7. Adjust or replace the coupling flange 8. Replace the bearing 9. Adjust or replace the axle housing
Hub bearing jamming	<ol style="list-style-type: none"> 1. Excessive pre-tightening force of the hub bearing 2. Inadequate lubrication of the bearing or incorrect usage of the grease 3. The bearing is defiled by the dust 4. Water entering bearing due to malfunction of sealing ring 	<ol style="list-style-type: none"> 1. Adjust the pre-tightening force 2. Intensify the lubrication or replace the grease 3. Clean and intensify the lubrication 4. Replace the sealing ring

Front axle and steering system

Fault symptom	Possible cause	Eliminating method
Steering wheel shimmy	<ol style="list-style-type: none"> 1. The steering system <ol style="list-style-type: none"> 1) Steering gear housing bolt or steering column supporting loose 2) Looseness of the steering connection point 3) Excessive clearance of the steering gear housing 2. The front axle <ol style="list-style-type: none"> 1) Unbalance or abrasion of the rim, the spoke and the wheel 2) Abrasion of the front wheel bearing 3) Excessive abrasion of the king pin or the bushing 4) Deformation of the knuckle 5) Improper wheel alignment 	<ol style="list-style-type: none"> 1) Tighten to specified torque 2) Adjust the junction 3) Adjust the clearance 1) Balance all the components and replace faulted components. 2) Replace the bearing 3) Adjust or replace the faulted parts 4) Replace the knuckle 5) Check and adjust the wheel alignment

Fault symptom	Possible cause	Eliminating method
	6) Fatigue of the front leaf spring, looseness of the "U" -bolt or damage of the central bolt	6) Replace the faulted parts
Failure of steering wheel return to center	<ol style="list-style-type: none"> 1. The steering system <ol style="list-style-type: none"> 1) Difficulty in the gear engagement 2) Malfunction of power steering system 3) Improper contact with the power piston 4) Fatigue of the return spring 5) Malfunction of slide valve 2. The front axle <ol style="list-style-type: none"> 1) Excessive caster angle of the king pin 	<ol style="list-style-type: none"> 1) Adjust the gear engagement 2) Overhaul and eliminate trouble 3) Adjust or replace the power piston 4) Replace the spring 5) Check diameter of the slide valve and the housing and replace them if necessary 1) Check and adjust the front wheel alignment
Misalignment of the steering wheel	<ol style="list-style-type: none"> 1. The alignment of front wheel incorrect 2. There has fatigue and damage in the front plate spring 3. Bending of the front axle 4. Unsmooth of the braking 5. Looseness of the front hub bearing nut 6. Inequality of the tire pressure 7. Tires with different dimension applied 	<ol style="list-style-type: none"> 1. Check and adjust the front wheel alignment 2. Replace the faulted spring 3. Adjust or replace the front axle 4. Please refer to the chapter "braking" 5. Tighten to specified torque 6. Inflate to the given pressure 7. Replace the tire by the correct type
Disproportion or untimely tire wear	<ol style="list-style-type: none"> 1. The front axle <ol style="list-style-type: none"> 1) Incorrectness of the wheel alignment 2) Abrasion or wreckage of the hub bearing and looseness of the bearing nut 3) Over looseness or tightness of the ball stud, the king pin and the bushing 2. Tire <ol style="list-style-type: none"> 1) Tire pressure incorrect 2) Misalignment between the tire and the wheel 	<ol style="list-style-type: none"> 1) Check and adjust the front wheel alignment 2) Replace the bearing or tighten nut to specified torque. 3) Make an adjustment and replace the faulted parts as needed 1) Supply to the given air pressure 2) Replace the tire or the wheel

Fault symptom	Possible cause	Eliminating method
Disproportion or untimely tire wear	3. Others 1) Breakdown caused by the abrupt starting or the emergent braking 2) Overloading	1) Correct the driving pattern 2) Make the loading according to the specified capacity
Heavy operation of the steering wheel (the steering system breakdown)	1. Too low oil level 2. Lubricant deterioration or impurity in it 3. Abrasion of the steering junction 4. Fault of the power steering system 5. Excessive lubricant resistance caused by the pipeline sunken 6. Too low oil pressure caused by the ineffective hydraulic pump 7. There has air in the hydraulic pipeline 8. Malfunction of rotary valve 9. Abrasion or damage of the power cylinder and damage of the piston O -ring 10. Too much leakage of the oil inside the steering gear housing	1. Add the lubricant to the given level 2. Replace the lubricant 3. Replace the ball stud 4. Overhaul and eliminate trouble. 5. Measure the backpressure and repair or replace the pipeline in case of the set value exceeded 6. Measure the oil pressure and the flow volume; disassemble and repair the hydraulic pump if the set value below 7. Bleed air and add oil. 8. Disassemble and repair rotary valve. 9. Disassemble and repair. 10. Disassemble and repair steering housing.
Heavy operation of the steering wheel (breakdown of the front axle)	1. Improper adjustment of the wheel alignment (excessive caster angle) 2. Too little clearance between the king pin and bushing 3. Inverse installation of the thrust bearing 4. Inadequate lubrication of the front axle parts 5. Over tight or loose connection of the bull 6. Too low tire pressure 7. Excessive abrasion of the tire	1. Check and adjust the wheel alignment 2. Check and adjust the clearance 3. Adjust the installation 4. Add the grease to the front axle 5. Check and lubricate the bulb stud 6. Inflate to the rated pressure 7. Replace the tire

There has oil spillage in the steering oil tank	<ol style="list-style-type: none">1. Clogging of the strainer or the filter element2. There has air in the pipeline	<ol style="list-style-type: none">1. Clean the filter strainer or replace the filter element2. Add the oil and make the exhaustion
---	--	---

Braking system

Fault symptom	Possible cause	Eliminating method
Unsmooth of the wheel	<ol style="list-style-type: none"> 1. There has compressed air inside the braking chamber 2. Improper lubrication of the camshaft or improper return of the adjusting arm 3. Brake shoe or chamber return spring fatigued or broken 4. The spring braking takes effect 5. Clogging of the exhaust port in the quick release valve 6. Brake valve primary or secondary piston return failure 	<ol style="list-style-type: none"> 1. Check and adjust the exhaust valve of the quick releasing valve 2. Adjust the faulted parts 3. Replace the faulted parts 4. Eliminate causes of the spring braking unreleased 5. Disassemble and clean the faulted parts 6. Disassemble and clean the braking valve and replace the faulted parts as needed
There has abnormal sound when treading the brake pedal	<ol style="list-style-type: none"> 1. The clincher or the bolt is projected because of abrasion of the braking friction lining 2. Surface hardening of the friction lining 3. Deterioration of the friction lining 4. Improperly contact between the brake shoe and the friction lining 5. Uneven abrasion of the brake drum internal surface or weak installation 6. Looseness of the brake shoe supporting 7. Abrasion of the hub bearing 8. Deformation of the brake drum 	<ol style="list-style-type: none"> 1. Replace the friction lining 2. Replace the friction lining 3. Replace the friction lining 4. Rivet the rivet or tighten bolt 5. Adjust or tighten the brake drum 6. Adjust the clearance between the brake shoes and tighten the supporting pin locknut 7. Replace the hub bearing 8. Adjust or replace the brake drum

Fault symptom	Possible cause	Eliminating method
Unsteady braking	<ol style="list-style-type: none"> 1. Tire pressure uneven or tire dimension different 2. Improper installation of the brake shoe or damage of the return spring 3. Improper engagement of the braking friction lining 4. Improper adjustment of the left and right brake 5. Deterioration of the braking friction lining 6. Oil on the braking friction lining 7. Damage of the brake backing plate 8. Looseness of the leaf spring U-bolt 	<ol style="list-style-type: none"> 1. Operate as required 2. Tighten the locknut of the brake shoe supporting pin and replace the return spring 3. Adjust the friction lining 4. Adjust the brake 5. Replace the friction lining 6. Clean with the gasoline to eliminate the effect of the leakage at the hub oil seal, oil cylinder cover and the rubber cap 7. Replace it 8. Tighten the U-bolt
The braking can't be applied under all conditions	<p>When compressed air pressure is normal:</p> <ol style="list-style-type: none"> 1. Too short of the brake valve travel 2. The camshaft doesn't rotate (the bushing is lack of lubricant) 3. Improper adjustment of the braking chamber pusher stroke 4. Improper sliding contact of the relay valve 5. Overheat or deterioration of the braking friction lining 6. Improper engagement of the braking friction lining 7. There has lubricant on the friction lining or the brake drum 8. Water entering brake drum 	<ol style="list-style-type: none"> 1. Check ,and replace the braking valve if necessary 2. Check working condition of the camshaft and replace it as needed 3. Adjust the travel 4. Disassemble and repair 5. Replace the friction lining 6. Adjust engagement position of the friction lining 7. Clean the oil trace with proper cleanser or replace the friction lining 8. Drying out the water by pressing the pedal gently during the running

Fault symptom	Possible cause	Eliminating method
	<p>When compressed air pressure is abnormal:</p> <ol style="list-style-type: none">1. There has air leakage inside the air pipeline2. The air compressor doesn't work3. The pressure regulator is improper adjusted or failed because of the impurity entering or air leakage in the brake valve	<ol style="list-style-type: none">1. Repair the leakage point2. Disassemble and repair air compressor3. Adjust or wash4. Disassemble and repair the brake valve

Common trouble and troubleshooting of electrical equipment and starting system

Fault symptom	Possible cause	Eliminating method
There has abnormal sound during the generator rotates	<ol style="list-style-type: none"> 1. The belt is of over loose or excessive abrasion with the shaking during the running 2. Bearing failure or oversize clearance 3. Too much bearing clearance 	Adjust the belt and replace the bearing
The charging indicator light doesn't go off during the running and the vehicle is difficult to start	<ol style="list-style-type: none"> 1. The battery is lack of power 2. The generator is damaged 3. Charging indicator lamp loop short 4. The belt is slipping 	<ol style="list-style-type: none"> 1. Charge the battery 2. Replace the generator 3. Check the circuit 4. Adjust the belt
The battery is lack of power excessively and incapable of charging at low speed	<ol style="list-style-type: none"> 1. The battery is damaged 2. The generator is damaged 3. The belt is slipping 	<ol style="list-style-type: none"> 1. Replace the battery 2. Replace the generator 3. Adjust the belt

Fault symptom	Possible cause	Eliminating method
Difficult in starting	<ol style="list-style-type: none"> 1. The battery has no power, or is lack of power or terminal loose 2. Poor contact of the starter switch, short circuit of the connector lug or bad of the solenoid 3. Starter pinion is clogged in the flywheel ring gear. Furthermore, engine bearing is burnt ,water on external of the combustion chamber and the consumption frozen may also caused the breakdown 	<ol style="list-style-type: none"> 1. Charge, clean the joint and screw it 2. Repair or replace it 3. Repair or replace it <p>Found out the reason and eliminate it</p>
Starting gear of the starter can not engage with the flywheel teeth	<ol style="list-style-type: none"> 1. Poor contact of the ignition switch or socket loose 2. Unsteady connection of the relay device or the solenoid switch 3. Turnoff of the starter solenoid switch 4. Damage of the starting gear or the gear ring of starter 5. Malfunction of engage switch 6. Starter armature shaft bent 	<ol style="list-style-type: none"> 1. Clean and tighten 2. tighten it 3. Replace it 4. Repair the teeth or replace it 5. Found out the reason and eliminate it 6. Replace it
Starting gear of the starter can not disengage completely	<ol style="list-style-type: none"> 1. Starter starting gear sleeve too tight or stuck 2. Too little clearance between the starting gear and the flywheel ring gear or the starter gear damage 3. Magnetic coil dirty 4. Clogging of the transmission fork shaft 5. Locking of the engage switch 	<ol style="list-style-type: none"> 1. Replace the shaft sleeve or clean and amend it 2. Adjust the clearance or replace the starting gear 3. Clean it 4. Clean and adjust it 5. Replace it

Common trouble and troubleshooting of air conditioner system

The remedy and trouble analysis under abnormal pressure

No.	Pressure	Description	Analysis	Remedy
1	The high and low pressure is lower than normal.	There is bubble in the inspection glass ; the cold air in the bus insufficient ; high pressure pipe a little bit warm and the low pressure pipe a little bit cold, the temperature difference is not too much;	The refrigerant filling is not enough and the system is leaking	Check the system for the leakage and find out the leaking point And make the maintenance Fill in refrigerant
	The high and low pressure are higher than normal		The refrigerant is too much	Drain some part of the refrigerant or refrigerant oil
2	The high and low pressure are much lower than normal .	No liquid flow seen from the inspection glass; Almost no refrigeration Almost no temperature difference between high and low pressure pipe	Air conditioner system has serious leakage	Check the system and find out the leakage point and fill the enough refrigerant
3	The low pressure is nearly to zero or even the negative value; The high pressure is lower than the normal value	No refrigerate in the system The front or the rear part of the expansion valve has fog	expansion valve blocked; expansion valve temperature sensor damaged or packing error	Changed the expanding valve Change the expanding valve temperature sensor Make good package for the expanding valve
	The high pressure and the low pressure are abnormal; The pressures are higher than the normal values	The temperature of the sucking pipe is lower than the normal value and the frosting appeared	expansion valve opened too much	Change the expanding valve Readjust the expanding valve
	The high pressure is higher than the normal value and the low pressure is lower than normal	The surface for the air suction pipe of the compressor has frost or condensate	Expanding valve damaged	Change the expanding valve

No.	Pressure	Description	Analysis	Remedy
4	The high and low pressure are much higher than the normal value and the needle of the gauge swing obviously	The cooling capability is insufficient and the system has air and the bubbles seen in the inspection glass	Air mixed in the refrigerant The vacuum is not good for the first time filling refrigerant or after the maintenance	Discharge the refrigerant in the system and change the desiccators and also make the vacuum repeatedly for filling the refrigerant
5	The high pressure is higher than the normal value and the low pressure is nearly to zero or negative value and the gauge swing seriously	The air sent to the bus sometime cold and sometimes warm and the inspection glass looks yellow	Too much water in the system desiccators reaching the saturation the frosting water blocked the expanding valve	Change the desiccators and make the vacuum repeatedly and then re-fill the refrigerant
6	The low pressure is much higher than the normal value and the high pressure is a little bit higher than the normal value	Cold is in sufficient	The condenser blower doesn't work normally or there is blockage in the condenser radiator	Check the electric circuit diagram or cleaning the condenser
7	The high and low pressure are higher than the normal values	The cold air is insufficient	Compressor interior failure	Repair or change the compressor
8	The high and low pressure are lower than the normal value	Evaporator wind flow is insufficient	Evaporator blower not running or low in efficiently or the radiator of the evaporator blocked	Check the electric circuit diagram or clean the evaporator radiator

Electric system trouble and remedy

Fault symptom	Possible cause	Eliminating method
the power lamp on the control panel not light	<ol style="list-style-type: none"> 1. + no power supply; 2. D+ not connected well; 3. harness not tight; 4. control unit failure; 	<ol style="list-style-type: none"> 1. generator D+ no output, exchange the generator and repair 2. reconnect the cable D+; 3. reconnect the harness; 4. change the control panel or repair;
malfunction light on the control panel light up	<ol style="list-style-type: none"> 1. system pressure error; 2. pressure switch defective; 3. pressure switch harness not connected well; 4. harness connection not well; 5. control panel failure; 	<ol style="list-style-type: none"> 1. to connect the manifold gauge and eliminate the malfunction; 2. change the pressure switch and repair; 3. reconnect the pressure switch; 4. harness connection; 5. change the control panel or repair;
refrigerant lamp is not lighted up	<ol style="list-style-type: none"> 1. defrost sensor failure or connection problem; 2. temperature control sensor failure or connection problem; 3. temperature control sensor installation position not good ; 4. temperature control switch defective; 5. harness connection not reliable; 6. Control panel defective 	<ol style="list-style-type: none"> 1. change the defrost sensor or connect the cable again; 2. change the temperature control or connect the harness again; 3. re-install the temperature control into the correct position; 4. change the temperature control switch or repair; 5. harness connection again; 6. change the control panel or repair;
condenser fan not working	<ol style="list-style-type: none"> 1. malfunction lamp light up; 2. sensor failure; 3. relay failure; 4. fuse burnt; 5. battery not charge or connection loose; 6. harness connection not tight; 7. air blower connection loose; 8. air blower failure; 9. control panel failure; 	<ol style="list-style-type: none"> 1. check the problem according to the item 2; 2. change sensor or sensor connection cable; 3. change the relay or repair the relay of the connecting harness; 4. change the fuse; 5. change the battery or recharge the battery ,make the connection; 6. re-connect the harness; 7. connecting to the venting cable; 8. change the blower or repair; 9. change the control panel or repair;

Fault symptom	Possible cause	Eliminating method
compressor not working	<ol style="list-style-type: none"> 1. compressor clutch connecting cable not connected well; 2. clutch damaged; 3. malfunction lamp light up; 4. refrigerant light not lighting up; 5. relay out of work; 6. no harness connection to the battery; 	<ol style="list-style-type: none"> 1. reconnect the cable; 2. change the clutch or repair; 3. refer to the above-mentioned items;
evaporator blower not working	<ol style="list-style-type: none"> 1. relay not working; 2. battery no charge; 3. battery cable connected; 4. air blower harness not connected well; 5. harness connection not good; 6. venting blower cable not connecting well; 7. air blower or blower speed adjustable resistor failure; 8. control panel out of work; 	<ol style="list-style-type: none"> 1. change relay or repair or connect the relay connecting cable; 2. change the battery or recharge; 3. reconnect the battery cable; 4. change the fuse; 5. reconnect the harness; 6. reconnect the blower motor connecting cable; 7. change the air blower or change the resistor for repair; 8. change the control panel or repair

Driver tools table (one each)

No.	Part name	No.	Part name
1	Tool box	23	Slip joint pliers 8"
2	Combination wrench 8	24	Nipper pliers 6"
3	Combination wrench 10	25	Tire pressure gauge 0-1.4MPa
4	Combination wrench 12	26	Valve core wrench
5	Combination wrench 13	27	Filter wrench (φ66-φ110)
6	Combination wrench 14	28	Pry bar also used as rocker lever 55cm
7	Combination wrench 15	29	Pry bar also used as handle 50cm
8	Combination wrench 16	30	Pry bar booster 500X27X3mm
9	Combination wrench 17	31	Grease gun 400cm ³ (with hose)
10	Combination wrench 18	32	Socket wrench for wheel nut 41 (hexagon)
11	Combination wrench 19	32	Socket wrench for wheel nut 21 (foursquare)
12	Combination wrench 21	33	Torque bar 315X25X25
13	Combination wrench 22	34	Final drive locknut 46mm (hexagon)
14	Combination wrench 24	35	Wrench for front wheel hub bearing nut 65 mm (hexagon)
15	Combination wrench 27	36	Wrench for front wheel hub bearing nut 55 mm (hexagon)
16	Combination wrench 30	37	Wrench for rear wheel hub bearing nut 110 mm (hexagon)
17	S-double box wrench 13X15	38	Wrench for rear wheel hub bearing nut 102 mm (octagon)
18	Adjustable wrench 8"	39	Wrench for drive axle drain plug 13X13 (foursquare)
19	Adjustable wrench 12"	40	Wrench for access cover 6mm (hexagon)
20	Cross-head screwdriver 6"	41	Tool box
21	Flat-tip screwdriver 6*100MM	42	Jack 12.5t
22	Hammer 1 pound	43	Special tool box

The special tools above are applied when Dong Feng axles used, while other axles are applied, the driver tools may vary as below.

Name	Cancel	Number	Add	Axle manufacturer
Wrench for front wheel hub bearing nut	70mm hexagon	1	60X72 mm foursquare	ZF Front axle
	70mm hexagon	1	2.25" or 57 mm hexagon	MeiChi Front axle
	70mm hexagon	1	58 mm hexagon	North Benz Front axle
	70mm hexagon	1	60 mm hexagon	Dong Feng portal axle
	55mm hexagon	1	41 mm fork hexagon	Hunan axle
Wrench for rear wheel hub bearing nut	110 mm hexagon	1	4.03" or 102 mm hexagon	MeiChi Rear axle

Final drive locknut	55 mm hexagon	1	51 mm hexagon	Fangsheng rear axle(imported final drive) or Hangzhou sanhua 9T and 9.5T rear axle
Socket wrench for wheel nut	32 mm hexagon	1	41 mm hexagon	Dongfeng Dena or Hangzhou sanhua 9.5T rear axle
	41 mm hexagon		21 mm foursquare	
	21mm foursquare		38 mm hexagon	Hunan axle
			22 mm foursquare	
Spare wheel lifter	22X550mm (Used in all tour buses.)			Not used in city buses.

Tightening torque of main bolts and nuts

Position		Tightening torque (N·m)
Propeller shaft bolt (Bolt grade: 10.9 G)	M16×1.5×L	270~330
lock nut, steering knuckle limiting bolt (M16)		80~100
Fixing nut, upper knuckle(M20)		280~350
Binding nut, tie rod (M12)		75~100
fixing nut ,ball pin of steering drag rod (M24)		280~300
Lock nut, steering wheel (M18)		60~80
fixing bolt , pitman arm and steering gear(M22)		570
Front tire nut	Dongfeng axle	580~650
Rear tire nut	Dongfeng axle	560~650
Fixing nut, front axle U type bolt		320~350
Fixing nut, rear axle U type bolt		360~440
Connecting nut, between upper knuckle and steering knuckle		280~350
Nut, trapeze form arm of Steering (left and right)		350~450
King pin uniform lock nut		25~40
Adjusting nut, front wheel hub bearing		Min200
Steering knuckle tie rod ball joint nut		250~310
Fixing nut ,tie rod ball joint		40~60
Connecting nut between Brake drum and wheel hub		295~412
Fixing nut, Front brake chamber and bracket		40~60
Fixing bolt, bracket of brake chamber		58~77
Fixing bolt, brake backing plate and steering knuckle		160~210
Fixing nut, Wheel		550~600
King pin screw-plug		60~80
Screw—fixing dust-proof cover		10~20
Fixing bolt, wheel hub bearing cap		16~23
Drain plug (M24X2)		130~150
Fixing nut, Rear brake backing plate (M16X1.5)		225~265
Drive bevel gear flange fixing nut (M36X1.5)		400~540

Driven bevel gear bolt (M20X1.5)	580~680
Lock nut, front and rear steel plate pin	55~70
Lower slotted nut, front damper (M20)	100~120
Lower slotted nut, rear damper (M20)	100~120
Bolt, bearing cap (M22X1.5)	440~490
Axle shaft bolt (M16X1.5)	140~180
Fixing bolt, bracket of brake chamber (M14X1.5)	90~120
Oil level hole plug (M24X2)	130~150
Fixing nut, rear brake chamber (M16X1.5)	170~190
Bearing saddle bolt (M14X1.5)	120~140
Differential house bolt(M16 X1.5)	220~280
Bolt-stopper shim	31~41
Bolt, between final drive and rear axle house(M12 X1.5)	130~150
Wheel bolt(M24X1.5)	420~490
Connecting nut, wheel hub and brake drum(M22X1.5)	300~420
Rear adjusting nut(M84X2)	Min500
Bolt, engine front suspending bracket	90~110
Connecting bolt , fly wheel house and frame bracket	80~100
Fixing bolt, clutch and fly wheel	90~100
Fixing bolt, between fly wheel house and clutch houseM10	60~65
Fixing bolt, between Transmission and clutch house M18	290
Fixing nut, transmission output rear connecting plate M10	49

Bolts torque table

Torques for bolts with metric unified threads			
Dimension of bolt	Torques N.m*(ft-lb)		
	8.8	10.9	12.9
M4	3(2)	5(3)	5(4)
M5	6(4)	9(7)	10(7)
M6	10(7)	15(11)	18(13)
M8	25(18)	35(26)	45(33)
M10	50(37)	75(55)	83(61)
M12	88(65)	123(91)	147(108)
M14	137(101)	196(145)	235(173)
M16	211(156)	300(221)	358(264)
M18	290(213)	412(303)	490(361)
M20	412(304)	578(426)	696(513)
M22	560(413)	785(559)	942(695)
M24	711(524)	1000(738)	1200(885)
M27	1050(774)	1480(1092)	1774(1308)
M30	1420(1047)	2010(1482)	2400(1770)
Torques for bolts with metric fine threads			
Dimension of bolt	Torques N.m*(ft-lb)		
	8.8	10.9	12.9
M8×1	26(19)	37(27)	48(35)
M10×1.25	52(38)	76(56)	88(65)
M12×1.25	98(72)	137(101)	126(119)
M12×1.5	93(69)	127(94)	152(112)
M14×1.5	152(112)	216(159)	255(188)
M16×1.5	225(166)	318(235)	383(282)
M18×1.5	324(239)	466(344)	554(409)
M20×1.5	461(340)	628(463)	775(572)
M22×1.5	618(456)	863(636)	1058(780)
M24×2	780(575)	1096(808)	1294(954)
M27×2	1147(846)	1578(1164)	1920(1416)
M30×2	1568(1156)	2254(1662)	2695(1988)

The torque values allow bolt yield strength up to 90%, assuming a friction coefficient of μ


Illustration for spare tyre dismounting & mounting

A. Dismounting the spare tyre


- 1、 loose the 2 nuts below spare tyre and take them down.




- 2、 fetch out the rubber stopper from front step , while the crowbar is inserted in the groove belong to hoisting rocker, then rotate it anticlockwise, you see, the spare tyre fall down slowly until landing the floor.



- 3、 remove the spare tyre's bracket and iron chain from rim .




- 4、 rotate the hoisting rocker clockwise, and make both the bracket and iron chain raise until returning back the initial position, then the spare tyre could be used after the vehicle leave.



B. Mounting the spare tyre


- 1、 Move the spare tyre under spare tyre's bracket, rotate the rocker anticlockwise until the bracket landing the floor ,next, put it into the spare tyre rim .






2、 Rotate crowbar clockwise to raise spare tyre until the height that keep rim stick on the lower surface of beam.

Attention: keep alignment between 2 bolts in chassis frame and 2 bolt holes in rim, meanwhile, assure bolts come out from rim.



3、 Fasten the wheel nuts, then take back the spare tyre's rocker into the tool box .



The Operation Tips for Maintenance Free Lead-acid Batteries

1. Safety

1.1 There is some vitriol liquid in the batteries, which is corrosivity. Please keep away from kids. Please must wear protective glasses and rubber gloves when operating. If the vitriol put into eyes, skin and clothes carelessly, please wash by a lot of water right now, the severe injured should go to hospital.

1.2 There exits hydrogen and oxygen when charging. Once emerge open fire or exhaust hole jamming, it will cause explosion. So the batteries should keep away from open fire and avoid short circuit.

1.3 The shell of batteries is made up polypropylene by injection molding. So it should be kept away from open fire because the polypropylene is inflammable.

2. Storage

2.1 The products series is electrolyte lead-acid batteries, it should store in dry, clean and ventilated environment , its'temperature range between 5 and 25 centigrade degree. It should not be touched into direct sunshine and heat source away from less than 2m .If the environment temperature is too high, it will impact on batteries' function.

2.2 The batteries should not be inversely laid, shocked and repressed by machine.

2.3 The storage period of batteries is 6 months at room temperature. The batteries need not be charging in the 6 months. If the storage period overpass more than 6 months, it can be used only after charging.

3. Charging

There exits hydrogen and oxygen in the later charging period, so it causes the water loss. The higher of charging voltage ,the bigger the water losing . The batteries series need not add water during using. So we strongly suggest constant voltage charging, try to avoid constant current charging.

3.1 Replenish charging

3.1.1 Constant current charging

It is charging 2 to 4 hours by one tenth of batteries capacity.

3.1.2 Constant voltage charging

It is constant voltage charging 16 hours by 16.0V. (the max current no more than 25A)

3.2 Normal charging

3.2.1 Constant current charging

It is charging 2 to 4 hours by one-twentieth of batteries capacity, when voltage is to 14.4V, and continue charging 2 to 3 hours.

3.2.2 Constant voltage charging

It is constant voltage charging 20 hours by 16.0V. (the max current no more than 25A)

3.3 There exits gas when charging. In order to avoid exploding, so should check the exhaust hole on the top of batteries frequently.

3.4 Please connect charging machine positive with batteries positive, and connect charging machine negative with batteries negative. No reverse charging.

3.5 In order to avoid electrolyte splashing for too high temperature, you should decrease charging voltage or charging current if the electrolyte temperature is more than 45°C .

4. Installation

4.1 In order to avoid unnecessary failure, should pay attention to safety mark before installation.

4.2 In order to avoid corrosion, should smear Vaseline on battery terminal before installation.

Connection should be steady and dependable. Do not knock the terminal to avoid it loosening and inner acids leaking.

4.3 Connect batteries positive with vehicle or engine positive first at installation, then connect batteries negative with vehicle or engine negative.

4.4 In order to avoid batteries damage, Please fix the battery firmly in the battery bracket .

5. Maintenance

5.1 There is the indicator of electric charge on the batteries cover. When the indicator shows green, the batteries use normally. When the indicator shows black, the batteries should be charged in time. When the indicator shows white, should change in time.

5.2 It should be charged in time if the battery capacity decrease for any reason.

5.3 The battery should avoid over-charging during charging to prolong its' service life.

5.4 It should be dismantled from the vehicle and stored in a dry and ventilative place if disused for a long time (normally more than 15days). It should be charged again every 3 to 6 months. (It depends on the indicator shows black).

The table of Lubricant, Power steering oil and Grease

1 Main assembly lubricant

Oil site	Lubricant	Type	Level
Engine	Diesel engine oil	15W/40	API CH – 4/SG
Transmission	Gear oil	SAE 85W-90	API GL – 4
Main reducer	Gear oil	SAE 85W-90	API GL – 5

Explanation : 1) Diesel engine oil--API CH -4/SG ,15W/40 , be used upwards -10°C
 10W API CH– 4/SG be used between -5°C ~ -20°C
 5W/30 API CH– 4/SG be used upwards -25°C
 2) Gear oil – could be used between -20°C ~ 50°C


2 Power steering oil

Fulfill standard: please apply **DEXRON-II D or DEXRON-III** hydraulic fluid to steering gear;


3 Others

Oil Site	Oil used	Nominate
Clutch	Synthesize grade oil	Nominate to use DOT3, DOT 4, etc.,
Bearing and ball pin	Li - grease	2#
Coolant	Nominate to use SINOPEC brand, YF-2A (upward -45°C centigrade) coolant, can't mix to use different type coolant	


Air braking schematic diagram



Electric schematic diagram of the complete car (1)




Electric schematic diagram of the complete car (2)



1 instrument	13 driver window	25 fuel sensor	37 right brake shoe (the 2 axle)	43	49 mid door cylinder microswitch
2 CPU controller with running recorder	14 driver window lifter switch	26 water temperature sensor	38 left brake shoe (the 3 axle)	44 front door switch	50 mid door relay
3 printer display	15 driver window lifter motor	27 speedometer sensor	39 right brake shoe (the 3 axle)	45 front door cylinder microswitch	51 mid door lamp
4 emergency switch	16 VITI-CLQ272M CPU	28 tachometer sensor	40 emergency door warning switch	46 front door electro-magnetic valve	52 passenger door remote controller
5 turn signal switch	17 Switch Oil pressure warning	29 Sensor, air pressure 1	41 retarder high temperature warning	47 mid door switch	53 ABS butt joint assembly
6 lamp switch	18 hand brake lamp switch	30 sensor, air pressure 2	42	48 mid door electro-magnetic valve	54
7 brake lamp switch	19 cabin temperature sensor	31 Air pressure warning switch 1		43	49 mid door cylinder microswitch
8 front fog lamp switch	20 coolant level switch	32 air pressure warning switch 2		44 front door switch	50 mid door relay
9 rear fog lamp switch	21	33 III speed electromagnetic clutch fan		45 front door cylinder microswitch	51 mid door lamp
10 wash room Water label warning switch	22	34 front left brake shoe		46 front door electro-magnetic valve	52 passenger door remote controller
11 driver deforster switch	23 Warning lamp switch of air filter block	35 front right brake shoe		47 mid door switch	53 ABS butt joint assembly
12 driver deforster relay	24 Oil pressure sensor	36 the 2 axle left brake shoe		48 mid door electro-magnetic valve	54


Electric schematic diagram of the complete car (3)



1 spare power connecting	7 left reverse lamp	13 door emergency valve rotated warning	19 left Side sign lamp	25 dryer	31 right front fog lamp	37 left rear fog lamp	43 wiper relay
2 wash room switch	8 right reverse lamp	14 stop switch	20 right Side sign lamp	26 left high beam	32 left brake lamp	38 right rear fog lamp	44 wiper motor
3 toilet power relay	9 Reverse monitor	15 service switch	21 left height lamp	27 right high beam	33 right brake lamp	39 left front turning lamp	45 scrubber motor
4 toilet	10 C2M271 lamp control module	16 monitor switch	22 right height lamp	28 left low beam	34 flowing axle electro-magnetic valve	40 right front turning lamp	46 daytime lamp switch
5 toilet occupied indicator	11 Following axle locked switch	17 door emergency valve cover open warning	23 left front Position lamp	29 right low beam	35 left turning lamp	41 Knob switch indicate	47 wiper high speed relay
6 Reverse lamp switch	12 door emergency valve cover open warning		24 right front Position lamp	30 left front fog lamp	36 right turning lamp	42 wiper switch	48

6125BYD4-0000-3700003				
图例	图例	图例	图例	图例
主图	电气原理图	20111108	666	
比例	1:1			
审核				
编制				

Electric schematic diagram of the complete car (4)



1 TV2 power switch	11 electric clock	21 reading lamp switch	31 rear windshield motor	41 rear number plate	51 rear blower switch	61 capacitance
2 TV1 power switch	12 driver lamp	22 left reading lamp relay	32 horn relay	42 inner display switch	52 rear high speed blower motor	62 resistance
3 Switch,TV overturn	13 left daylight switch	23 left reading lamp	33 horn button	43 inner display	53 rear low speed blower motor	63 diode group
4 TV1	14 daylight controller	24 right reading lamp relay	34 Horn switch assy	44 rear view power interface	54 heater controller	64 control relay
5 TV2	15 left front daylight lamp	25 right reading lamp	35 Electric horn	45 cetralized lubrication power interface	55 heater	65 capacitance box
6 DVD player	16 left rear daylight lamp	26 Switch, luggage compartment	36 damp electric solenoid valve	46 deforster switch	56 air-condition panel	66
7 left front speaker	17 right daylight lamp switch	27 luggage compartment lamp	37 front windshield switch	47 deforster motor	57 150A air condition fuse	67
8 left rear speaker	18 daylight lamp control	28 front windshield switch	38 outer number plate switch	48 front blower switch	58 generator for air-condition	68
9 right front speaker	19 right front daylight lamp	29 front sky window motor	39 front number plate	49 front high speed blower motor	59 air-condition evaporator and condenser	69 condenser
10 right rear speaker	20 right rear daylight lamp	30 rear sky window switch	40 side number plate	50 front low speed blower motor	60 Air-condition compressor	70

6125BYD4-0000-3700004					
图例	图例	图例	图例	图例	图例
电气系统原理图三	备注	比例	日期	版本	1:1 1
奇瑞汽车股份有限公司					
奇瑞汽车股份有限公司					